

OSCILLOSCOPE CAMERA

197A

SN PREFIX = 1528A



HEWLETT  PACKARD

CERTIFICATION

The Hewlett-Packard Company certifies that this instrument was thoroughly tested and inspected and found to meet its published specifications when it was shipped from the factory. The Hewlett-Packard Company further certifies that its calibration measurements are traceable to the U.S. National Bureau of Standards to the extent allowed by the Bureau's calibration facility.

WARRANTY AND ASSISTANCE

This Hewlett-Packard product is warranted against defects in materials and workmanship. This warranty applies for one year from the date of delivery, or, in the case of certain major components listed in the operating manual, for the specified period. We will repair or replace products which prove to be defective during the warranty period provided they are returned to Hewlett-Packard. No other warranty is expressed or implied. We are not liable for consequential damages.

Service contracts or customer assistance agreements are available for Hewlett-Packard products that require maintenance and repair on-site.



OPERATING AND SERVICE MANUAL

MODEL 197A OSCILLOSCOPE CAMERA

SERIAL NUMBERS

This manual applies directly to instruments with serial numbers prefixed 1528A.

With changes described in Section VII, this manual also applies to instruments with serial numbers prefixed: 610-, 730-, 805-, 905-, 913-, and 1203A.

Refer to Section I for instruments with the following standard options: 003, 005, 006, 007, and 012.

HEWLETT-PACKARD COMPANY/COLORADO SPRINGS DIVISION
1900 GARDEN OF THE GODS ROAD, COLORADO SPRINGS, COLORADO, U.S.A.

Manual Part Number 00197-90907
Microfiche Part Number 00197-90807

PRINTED: OCTOBER 1975

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

GROUND THE INSTRUMENT.

To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument is equipped with a three-conductor ac power cable. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet. The power jack and mating plug of the power cable meet International Electrotechnical Commission (IEC) safety standards.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DANGEROUS PROCEDURE WARNINGS.

Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

WARNING

*Dangerous voltages, capable of causing death, are present in this instrument.
Use extreme caution when handling, testing, and adjusting.*

TABLE OF CONTENTS

Section	Page	Section	Page
I GENERAL INFORMATION	1-1	IV PRINCIPLES OF OPERATION.....	4-1
1-1. Introduction	1-1	4-1. Introduction	4-1
1-5. Specifications	1-1	4-3. Instrument Description	4-1
1-7. Accessories Supplied	1-1	4-5. Camera Back	4-1
1-9. Accessories Available	1-1	4-8. Lens Assembly	4-1
1-11. Options	1-1	4-10. Shutter	4-2
1-13. Instrument and Manual		4-12. Timing Circuit	4-2
Identification	1-2	4-16. Shutter Actuation	4-2
		4-20. Power Supply	4-3
II INSTALLATION	2-1	V PERFORMANCE CHECK AND	
2-1. Introduction	2-1	ADJUSTMENTS	5-1
2-3. Initial Inspection	2-1	5-1. Introduction	5-1
2-5. Power Cables and Receptacles.....	2-1	5-3. Performance Check	5-1
2-7. Power and Environmental		5-5. Shutter Operation.....	5-1
Requirements	2-1	5-6. Light Leakage	5-1
2-9. Mounting Instructions	2-2	5-7. Adjustments	5-1
2-12. Repacking for Shipment	2-2	VI REPLACEABLE PARTS	6-1
III OPERATION	3-1	6-1. Introduction	6-1
3-1. Introduction	3-1	6-3. Ordering Information	6-1
3-3. Camera Controls.....	3-1	VII MANUAL CHANGES	7-1
3-5. Viewer Lever	3-1	7-1. Introduction	7-1
3-6. Shutter Sync Jacks	3-1	7-3. Manual Changes.....	7-1
3-7. Shutter Speed Switch	3-1	7-5. Option 012 Wiring Diagram	
3-8. Lens f/No. Control.....	3-1	Change	7-1
3-9. Remote Shutter Jacks	3-1	7-7. Manual Changes Listing.....	7-1
3-10. Object-to-image Ratio		VIII SCHEMATICS AND TROUBLE-	
Adjustment	3-1	SHOOTING	8-1
3-11. Multiple Picture Detent	3-1	8-1. Introduction	8-1
3-12. Film Description	3-1	8-3. Schematic	8-1
3-14. CRT Phosphor	3-1	8-6. Preventive Maintenance	8-1
3-17. Film Loading	3-3	8-8. Mechanical Inspection	8-1
3-19. Operating Procedures	3-3	8-11. Camera Back Cleaning	8-1
3-20. General Considerations	3-3	8-12. Lens Cleaning	8-1
3-24. Focus	3-3	8-13. Lubrication	8-1
3-25. Recurrent Sweep Exposures	3-3	8-14. Repair and Replacement	8-1
3-27. Single Sweep Exposure.....	3-5	8-16. Side Panel Access.....	8-2
3-29. Multiple Exposures	3-5	8-17. Servicing Etched Circuit	
3-30. Object-to-image Ratio		Boards.....	8-2
Adjustment	3-5	8-19. Troubleshooting	8-2
3-31. Remote Shutter and		8-22. Print Quality Improvement	8-2
Shutter Synchronization	3-6	8-24. Light Leakage	8-2
3-33. External Graticule Consideration..	3-6	8-25. Fogging	8-3
3-35. Parallax	3-6	8-28. Film Tearing	8-3
3-37. Depth-of-field	3-7	8-29. Print Imperfections	8-3
3-38. Film Developing	3-7		

LIST OF ILLUSTRATIONS

Figure	Title	Page	Figure	Title	Page
2-1.	Power Cable Configurations.....	2-1	7-1.	Option 012 Wiring and Fuse Change ...	7-1
2-2.	Model 197A Installation.....	2-2	7-2.	Shutter Control Component Identification	7-2
3-1.	Model 197A Controls.....	3-2	7-3.	Shutter Control Schematic	7-3
3-2.	Film Loading	3-4	7-4.	Model 197A Exploded View	7-4
3-3.	Parallax Effects	3-6	7-5.	Shutter Control Schematic	7-11
3-4.	Film Developing	3-8			
4-1.	Camera Back Operation.....	4-1	8-1.	Output Circuit A1 Component Identification	8-4
4-2.	Shutter Control Block Diagram	4-2	8-2.	Timing Circuit A2 Component Identification	8-5
6-1.	Model 197A Exploded View	6-0	8-3.	Shutter Control Schematic	8-5

LIST OF TABLES

Table	Title	Page	Table	Title	Page
1-1.	Specifications.....	1-1	7-1.	Manual Changes.....	7-1
2-1.	Environmental Limits	2-1	7-2.	Replaceable Parts for Instrument Serial Prefixes 610 through 913-	7-6
6-1.	Abbreviations for Replaceable Parts List.....	6-1			
6-2.	Replaceable Parts.....	6-2	8-1.	Camera Lubrication Points.....	8-1
6-3.	List of Manufacturers' Codes.....	6-5			

SECTION I

GENERAL INFORMATION

1-1. INTRODUCTION.

1-2. The Hewlett-Packard Model 197A is a versatile, general-purpose, oscilloscope camera that can be used for many trace recording applications. All controls are readily accessible for easy reading and fast adjustment during setup. The controls are also color coded for optimum settings for most photographs which reduces initial setup time.

1-3. An electronically-controlled shutter, with all solid-state circuits for reliable operation, provides accurate exposure times from 1/30 to 4 seconds. The shutter may be operated remotely by providing a closure to ground. A contact closure is also provided when the shutter is open to allow synchronization of other equipment.

1-4. This section of the manual contains specifications for the Model 197A. It also lists accessories supplied with the instrument and other accessories and options that are available. Instrument and manual identification information are also included.

1-5. SPECIFICATIONS.

1-6. Table 1-1 is a complete list of Model 197A critical specifications. Any changes in specifications due to manufacturing, design, or traceability to the U.S. National Bureau of Standards will be listed on a manual change sheet included with this manual. The manual and the manual change sheet (if any) supersede all previous information concerning specifications of the 197A.

1-7. ACCESSORIES SUPPLIED.

1-8. The following accessories are supplied with the 197A:

One Split-image Focus Plate, HP Part No. 1000-0226
One Power Cable, HP Part No. 8120-1348

1-9. ACCESSORIES AVAILABLE.

1-10. The following accessories are available for the 197A:

Model 10352B Graflok 10- x 13-cm (4- x 5-in.) back
Model 10353A Polaroid Land pack-film back
Model 10354A Viewing hood replacement plate
Model 10355A Tektronix or Dumont 5-in. bezel adapter

Model 10356A Tektronix 560-series adapter
Model 10357A Tektronix 640-series adapter
Model 10358A Carrying Case
Model 10367A HP Model 182A Oscilloscope bezel adapter
Model 10375A Front-mount adapter for the following X-Y Displays: HP Models 1332A and 1335A; Tektronix Models 601, 602, 603, 604, and 605.

1-11. OPTIONS.

1-12. The following available options extend the usefulness of the Model 197A:

Option 003. This option provides the Graflok 10- x 13-cm (4- x 5-in.) camera back. The Graflok back can be used with various film-holder adapters, depending on requirements of the user.

Table 1-1. Specifications

REDUCTION RATIO: continuously adjustable from 1:1 to 1:0.7. Reference scale provided on focus plate.

LENS: 75 mm, f/1.9 high-transmission lens; aperture ranges f/1.9 to f/16.

SHUTTER SPEEDS: 1/30, 1/15, 1/8, 1/4, 1/2, 1, 2, and 4 seconds, Time and Bulb; shutter has a sync contact closure output for triggering external equipment and an input jack for remote operation.

CAMERA BACK: 82.6 mm x 108.0 mm (3-1/4 in. x 4-1/4 in.). Polaroid pack back (other backs are available, see Options); backs are interchangeable without focusing and may be rotated in 90-degree increments.

MOUNTING: lift on/off mounting with positive lock, swing-away hinging to left. Mounts directly on most HP oscilloscopes with 12.7 cm (5 in.) round or rectangular CRTs. Adapters are available to fit many other scopes.

VIEWING: low-angle, direct viewing through a flexible facemask.

MULTIPLE EXPOSURE: back can be moved through 11 detented positions (0.5 cm per detent at 1:0.9 object-to-image ratio).

FOCUS: adjustable focusing with lock; split image focusing plate provided.

DIMENSIONS: 356 mm long, 267 mm high, 194 mm wide (14, 10-1/2, 7-5/8 in.).

WEIGHT: net, 4.5 kg (10 lb); shipping, 7.3 kg (16 lb).

POWER: 115 V $\pm 10\%$, 50 to 400 Hz, 6 watts.

Option 005. This option provides a special cable (HP Part No. 00197-61606) to be used when synchronizing the camera with other equipment. The cable is 45.7 cm (18 in.) long with a phone jack on one end, and a 2-pin banana plug on the other end which mates with J1 or J2 on the camera control panel.

Option 006. This option consists of the standard instrument modified with a front-bezel mount to facilitate attachment to certain HP X-Y Display instruments (Model 1332A and 1335A), and certain displays built by other manufacturers (such as Tektronix Models 601 through 605). The front mount may be purchased as an accessory (HP Model 10375A) for conversion of the standard instrument.

Option 007. This option is the standard instrument modified to meet the U.L. listing requirements for medical and dental equipment. To meet the safety requirements of a hospital atmosphere, changes and additional features have been added to the standard instrument. Further information is available from your HP Sales/Service Office.

Option 012. This option is a standard instrument with the power input circuit wired for 230-volt ac operation.

Main fuse (F1) is changed to .062 ampere (HP Part No. 2110-0311). Refer to Section VII for circuit information.

1-13. INSTRUMENT AND MANUAL IDENTIFICATION.

1-14. Instrument identification by serial number is located on the bottom plate of the instrument. Hewlett-Packard uses a two section serial number consisting of a four-digit prefix and a five-digit suffix, separated by a letter designating the country in which the instrument was manufactured. (A = U.S.A.; G = West Germany; J = Japan; U = United Kingdom.)

1-15. This manual applies to instruments with a serial prefix number as shown on the title page. If changes have been made in the instrument since this manual was printed, a "MANUAL CHANGES" supplement supplied with the manual will define these changes. Be sure to record these changes in your manual. Backdating information in Section VII adapts the manual to instruments with serial numbers lower than that shown on the title page. Part numbers for the manual and the microfiche copy of the manual are also shown on the title page.

SECTION II

INSTALLATION

2-1. INTRODUCTION.

2-2. This section contains information and instructions necessary for installing the Model 197A Camera. Included are initial inspection procedures, power and grounding requirements, installation instructions, and procedures for repacking the instrument for shipment.

2-3. INITIAL INSPECTION.

2-4. This instrument was carefully inspected both mechanically and electrically before shipment. It should be free of marks or scratches and in perfect operating condition upon receipt. To confirm this, the instrument should be inspected for physical damage that may have incurred during transit. If the instrument was damaged in transit, file a claim with the carrier. Check for supplied accessories (listed in Section I) and test the performance of the instrument using the performance test procedures outlined in Section V. If there is damage or deficiency, see the warranty in the front of this manual.

WARNING

Read the Safety Summary at the front of the manual before installing or operating the instrument.

2-5. POWER CABLES AND RECEPTACLES.

2-6. Figure 2-1 illustrates the standard configurations used for HP power cables. The HP part number directly above each drawing is the part number for an instrument power cable equipped with a connector of that configuration. If the appropriate power cable is not included with the instrument, notify the nearest HP Sales/Service Office and a replacement cable will be provided.




HP POWER CABLE PART NUMBERS		
8120-1692	8120-1703	8120-1521
		
INPUT POWER RECEPTACLE TYPES		

Figure 2-1. Power Cable Configurations

2-7. POWER AND ENVIRONMENTAL REQUIREMENTS.

2-8. The 197A Camera can be operated from any power source of 115 Vac ($\pm 10\%$) at 50 to 400 Hz. For environmental limitations refer to table 2-1.

WARNING

If the oscilloscope chassis is not grounded, be sure that the connection of the grounded case of the camera to the oscilloscope will not present a shock hazard to operating personnel or damage the oscilloscope.

Table 2-1. Environmental Limits

Environmental Condition	With film	Without film
Maximum storage temperature	70°C*	75°C
Minimum storage temperature	-30°C	-40°C
Maximum operating temperature	50°C	55°C
Minimum operating temperature	-5°C	-20°C
Maximum relative humidity		
-5°C to 50°C	90%	
Over 50°C	50%	
25°C to 40°C		95%
<div style="border: 1px dashed black; padding: 5px; display: inline-block;">CAUTION</div>		
Avoid extended operation or storage under conditions of high humidity.		
Altitude:		
Operating	15 000 ft	
Nonoperating	25 000 ft	

*For a period not to exceed 8 hours.

2-9. MOUNTING INSTRUCTIONS.

2-10. The 197A Camera is designed to fit all oscilloscopes using the standard 14-cm (5-5/8 in.) diameter bezel, or an 11- x 14-cm (4-1/2 x 5-1/2-in.) rectangular bezel. The mounting frame is designed for 2-cm (3/4-in.) bezel depth, permitting direct attachment to most HP oscilloscopes. Refer to Section I for adapters to be used with oscilloscopes that will not accept the 197A directly. To mount the camera on a round bezel, see figure 2-2 for identification of parts and proceed as follows:

a. Adjust mounting lock knob (1) so that locking lever (2) is positioned approximately as shown in figure 2-2.

b. Mount camera on oscilloscope bezel. Press forward gently on camera until mounting retainers (3) hook over lip at rear of bezel.

NOTE

The light gasket (4) will be compressed slightly by this action, preventing light leakage into the camera.

c. Position camera so that camera horizontal axis is parallel with horizontal axis of CRT graticule.

d. Turn lock knob (1) clockwise until locking lever is tightened firmly against bezel. Note that lever also hooks over lip at rear of bezel.

2-11. The camera is mounted on a rectangular bezel in the same manner as described above, except that light gaskets (5) must be repositioned prior to mounting. Reposition the gaskets as follows:

a. Loosen two lock screws (6) inside mounting frame, one-quarter turn.

b. Lower gaskets until lock screws are at lower end of slots.

c. Tighten lock screws.

2-12. REPACKING FOR SHIPMENT.

2-13. If the instrument is to be shipped to a Hewlett-Packard Sales/Service Office for service or repair, attach a tag showing owner (with address), complete instrument serial number, and a description of the service required.

2-14. Use the original shipping carton and packing material. If the original packing material is not available, the Hewlett-Packard Sales/Service Office will provide information and recommendations on materials to be used.




Figure 2-2. Model 197A Installation

SECTION III

OPERATION

3-1. INTRODUCTION.

3-2. This section contains a brief discussion of the operating controls, operating procedures, and basic operating considerations for the Model 197A Oscilloscope Camera.

3-3. CAMERA CONTROLS.

3-4. Figure 3-1 identifies and describes the purpose of each control on the 197A. The following paragraphs provide more detailed descriptions of several of the controls.

3-5. **VIEWER LEVER.** A viewer lever on each side of the camera operates the viewer door to permit direct viewing of the CRT screen. The door should be closed when taking a picture, but in most cases enough light is blocked by the face to allow photographing while viewing.

3-6. **SHUTTER SYNC JACKS.** These jacks are connected together through a pair of switch contacts that close when the shutter is actuated, thus enabling synchronization of remote equipment with the shutter action.

3-7. **SHUTTER SPEED SWITCH.** This switch sets the length of time that the shutter remains open. The switch panel indicates the eight calibrated time intervals: 1/30, 1/15, 1/8, 1/4, 1/2, 1, 2, and 4 seconds. The two additional switch positions are B (bulb) and T (time). In B position, the shutter opens when the SHUTTER bar is pressed, and closes when the bar is released. In T position, pressing the SHUTTER bar will open the shutter, and pressing it again will close the shutter.

3-8. **LENS f/NO. CONTROL.** This control varies the lens opening (iris) and therefore, the intensity of light transmitted to the film. It is continuously variable from f/1.9 to f/16 (largest to smallest aperture, respectively). The larger the aperture, the shorter the required exposure time for a given film density.

3-9. **REMOTE SHUTTER JACKS.** These jacks are connected in parallel with the shutter control switch. This feature may be used with all shutter speeds and requires a shorting (or grounding) action from a remote source to actuate the shutter.

3-10. **OBJECT-TO-IMAGE RATIO ADJUSTMENT.** The object-to-image ratio for the 197A can be adjusted from 1:1 to 1:0.7. The ratio is varied by adjusting the bright-

headed screw that is visible when the camera back is moved to the top detent position.

3-11. **MULTIPLE PICTURE DETENT.** The detent button releases the camera back permitting vertical movement to any one of eleven positions. The camera back moves approximately 0.5 cm (0.2 in.) for each detent position, giving a total vertical trace position range of about 5 cm (2 in.) in equal increments. For single exposure pictures, the camera back should be in the center detent position as indicated by the raised pointer on the camera back mounting frame.

3-12. FILM DESCRIPTION.


3-13. The film used in the 197A is Polaroid Type 107 film pack that gives eight 8.3- x 10.8-cm (3-1/4- x 4-1/4-in.) exposures. The ASA exposure index for the film is 3000, which makes the film particularly suitable for recording extremely fast transients, as well as all repetitive traces. The prints are developed in 10 seconds by the Polaroid process. A print coater, supplied with each film pack, is used after development for permanence of the print. The negative and film pack cover are discarded after use. Copies and enlargements of the prints may be obtained through the Polaroid Copy Service (refer to instruction sheet supplied with the film pack).

WARNING

The Polaroid process uses a caustic reagent which is sealed in containers within the film pack. If the reagent should accidentally come in contact with the skin, wipe it off immediately. Wash the exposed area with water to avoid an alkali burn. It is particularly important to keep the reagent away from eyes and mouth. Keep the discarded materials out of reach of children and animals, and out of contact with clothing, furniture, and equipment because the discarded materials still contain some reagent.

3-14. CRT PHOSPHOR.

3-15. Although excellent photographs can be obtained with all commonly-used phosphors, the photographic efficiency of a given phosphor can be important when fast-single, or low-repetition sweeps are to be recorded. Type P11 phosphor has the most suitable light output (i.e., highest photographic efficiency) for photo-



- 197A-A-5A-10-75
1. **Viewer Lever.** Operates viewer door. (Close before exposure of film.)
 2. **SHUTTER SPEED Switch.** Determines length of time shutter is open.
 3. **SHUTTER SYNC Jacks.** Output connector for synchronization of external equipment with shutter actuation.
 4. **Swing-away Latch Release Button.** Push to release latch, allowing camera to swing-away to the left.
 5. **LENS f/NO. Control.** Determines intensity of light transmitted to the film.
 6. **Mounting Lock Knob.** Locks camera mounting frame to oscilloscope bezel.
 7. **SHUTTER Control Bar.** Press to actuate the shutter control switch.
 8. **REMOTE SHUTTER Jacks.** Input connector for actuating the shutter from a remote source.
 9. **LOCK Knob.** Locks FOCUS knob in desired position.
 10. **FOCUS Knob.** Adjusts camera focus.
 11. **Object-to-image Ratio Adjustment Screw.** Varies the object-to-image ratio.
 12. **Multiple Picture Detent Release Button.** Press to release detent for moving the camera back vertically in relation to the lens.
 13. **Camera Back Lock Release Button.** Push button to the left to open camera back.
 14. **Camera Back Lock Nuts (2).** Hold camera back in place on camera frame.

Figure 3-1. Model 197A Controls

graphic purposes and should be used when maximum writing rate is desired. Other phosphors, in descending order of efficiency are: P31, P2, P7, and P1.

3-16. In general, a filter over the CRT face degrades quality of the picture obtained, increases the required exposure, and on external graticule oscilloscopes will increase parallax distortion. It is recommended that any filter be removed before taking photographs. An exception is the use of a blue filter to eliminate cathode glow on some unaluminized phosphor CRT's. (A blue filter can also be used to eliminate yellow after-glow of long-persistence CRT's.)

3-17. FILM LOADING.

3-18. Complete film loading instructions are given in figure 3-2. The film is most easily loaded with the camera mounted on the oscilloscope; however, film can also be loaded with the camera unmounted.

3-19. OPERATING PROCEDURES.

3-20. **GENERAL CONSIDERATIONS.** The procedure required to photograph an oscilloscope display is subject to a number of variables that include: trace intensity, phosphor type, shutter accuracy, filters used, sweep duty cycle and speed, and limitations imposed by depth-of-field. To simplify operation of the 197A, the basic controls (i.e., shutter speed, and aperture) are color coded for optimal settings in normal situations. One or two trial exposures may be necessary when first operating the camera, or when the operating conditions are changed. The procedures given in the following paragraphs assume the use of an internal graticule oscilloscope with the 197A. Special considerations required for external graticule oscilloscopes are given in paragraph 3-33.

3-21. **CRT Filters.** Any filter over the CRT face should be removed before taking photographs, except for special purposes as discussed in paragraph 3-16.

3-22. **CRT Controls.** Trace intensity should be set for good trace detail. In some instances, compromises may be necessary to intensify fast-rise or fall portions of a waveform, or to match trace and graticule intensities. Focus and astigmatism should be adjusted for a sharp trace over the full display area; this should be done with a test signal prior to recording single-shot transients.

3-23. **Shutter Speed Limitations.** The shutter must remain open long enough to record at least one complete sweep, and preferably five to ten sweeps if no drift or jitter is present. When the display contains drift or jitter, the shutter speed should be fast enough so that only a few sweeps are recorded. It should be noted that the time scales on sampling oscilloscopes are not equivalent to sweep speeds on conventional oscilloscopes; since the scanning rate is not a cali-

brated function, special care should be taken so that at least five scans are recorded. Due to the time required for the shutter control circuit to recharge, succeeding shutter actuations should not be attempted at less than 10-second intervals.

3-24. **FOCUS.** Focusing of the 197A is completely adjustable, and is performed as follows:

a. Mount camera on oscilloscope and apply power to camera.

b. Move camera back to any detent position above center. Remove focus plate from storage compartment on camera bottom. Set camera back to center detent position.

c. Open camera back and insert focus plate.

NOTE

If there is a film pack in camera, it must be removed (this exposes top film in pack and it must be removed after pack is reinstalled in camera).

d. Set camera controls as follows:

SHUTTER SPEED	T
LENS f/NO.	1.9

e. Press SHUTTER bar to open shutter.

f. Verify that focus plate is flat against film frame with proper side toward lens. Adjust FOCUS control until vertical graticule line is no longer split when viewed simultaneously through top and bottom of split-image spot in center of focus plate.

g. When focus adjustment is complete, tighten FOCUS LOCK knob and recheck focus. Remove focus plate and replace in storage compartment. Close shutter and reset all camera controls to normal.


3-25. **RECURRENT SWEEP EXPOSURES.** The procedure given below assumes a stable display of normal intensity. If the display is unstable, a faster shutter speed (smaller number) should be used with a larger aperture (smaller number). It should be noted that approximately the same exposure is obtained by various combinations of shutter speed and aperture (i.e., 1/2 sec at f/5.6 and 2 sec at f/11 correspond to 1 sec at f/8). If the display intensity is weak, and cannot be improved by adjusting the oscilloscope intensity control, a larger aperture should be used with a slower shutter speed.

3-26. To photograph a recurrent sweep display, proceed as follows:

a. Set camera back to center detent position.

**STEP 1**


Unlock camera back cover by pushing lock button to left.

**STEP 2**

Clean rollers with clean, damp cloth or tissue paper.

STEP 3

With safety cover facing lens, and tabs to right, insert film pack by pushing gently to left and toward lens.

**STEP 4**

Close cover, being sure that black safety cover tab projects out of back from small No. 4 slot. Press both sides of back firmly to be sure they latch.

STEP 5

Pull safety cover out of camera to right. Safety cover comes free and must be removed completely before first exposure is made. White tab is now projecting from No. 4 slot, and camera is ready for first exposure.

197A-R-2-10-75

Figure 3-2. Film Loading

- b. Set camera controls as follows:

SHUTTER SPEED	1
LENS f/NO.	8

- c. Close viewer door.
- d. Press SHUTTER bar to actuate shutter.
- e. Develop print (figure 3-4).

NOTE

If print is overexposed (too light), use smaller aperture (larger f-number); if underexposed, use larger aperture.

3-27. SINGLE SWEEP EXPOSURE. Single-trace photography of fast transients is made possible by the high-sensitivity film now available. Single events which are too fast or too faint for the eye to detect can be captured on this film. In single-trace photography, the oscilloscope should be set up initially using a pulse generator operating at a low repetition rate (30 Hz or less) as a test signal. The low repetition rate avoids the increase in trace brightness caused by phosphor persistence when traces overlap, and permits optimum CRT focus adjustment. During this initial adjustment, the sweep speed should be set for the same speed to be used in the final photograph. To make a photograph of the desired transient, the camera shutter is held open manually on Bulb or Time while the oscilloscope sweep is triggered once by the signal being photographed. One precaution regarding external gratitudes concerns parallax (refer to paragraph 3-35) between trace and graticule; allowance for parallax should be made when adjusting the trace height and position. If an internal graticule CRT is being used, parallax is not present.

3-28. To photograph a single-sweep display, proceed as follows:

- a. Set camera back to center detent position.
- b. Set SHUTTER SPEED to T (or B).
- c. Set LENS f/NO. (aperture) wide open (f/1.9) if display is dim, or f/8 if normal. These are trial settings; experience with given conditions will indicate preferred settings. If large aperture is used, focusing becomes critical.
- d. Assure good visual presentation of signal when it appears. Set CRT intensity high, but not so high as to cause halo, overriding blanking gate, defocusing, or loss of detail. Check CRT focus on single-shot or low repetition rate signals.
- e. Close viewer door.
- f. Open shutter.

- g. Trigger single sweep.

- h. Close shutter.

NOTE

If it cannot be determined that shutter is open or closed, set SHUTTER SPEED switch to any position other than T to ensure that shutter is closed.

- i. Develop print (see figure 3-4).

3-29. MULTIPLE EXPOSURES. Multiple exposures on one photograph are made as follows:

- a. Set CRT intensity to normal and center display on CRT. Use low vertical amplitude. Vertical position control is not used after this.
- b. Move camera back to one of top detent positions (depending on number of exposures to be taken and vertical amplitude of each signal). Each detent position moves trace approximately 0.5 cm (0.2 in.) on exposed graticule.
- c. Expose display, either recurrent or single sweep (refer to paragraphs 3-25 and 3-27).
- d. Move camera back to lower detent position (as required).
- e. Obtain new display on oscilloscope.
- f. Repeat steps c through e for any number of exposures up to eleven.

3-30. OBJECT-TO-IMAGE RATIO ADJUSTMENT. Object-to-image (reduction) ratio of the 197A is adjustable from 1:1 to 1:0.7. The focus plate is imprinted with three scales that are used to set the ratio to 1:1, 1:0.9, or 1:0.7. Adjust ratio as follows:

NOTE

Ratios apply only to CRT gratitudes with 1 cm (0.4 in.) graticule lines.

- a. Mount camera on oscilloscope and apply power to camera.
- b. Move camera back to either one of the top two detent positions and remove focus plate from storage compartment on bottom of camera.
- c. Open camera back and insert focus plate.

NOTE

If there is a film pack in camera, it must be removed (this exposes top film in pack and it must be removed after pack is reinstalled in camera).

- d. Set camera controls as follows:

SHUTTER SPEED T
LENS f/NO. 1.9

- e. Press SHUTTER bar to open shutter.

f. Ensure focus plate is flat against film frame and adjust object-to-image ratio screw (figure 3-1) until graticule lines are aligned with scribe marks (for desired ratio) on focus plate.

NOTE

When adjusting camera for 1:1 ratio, it may be necessary to turn focus plate upside down.

g. When reduction ratio adjustment is completed, check focus and adjust if necessary.

h. Remove focus plate and replace in storage compartment. Close shutter and reset all camera controls to normal.

3-31. REMOTE SHUTTER AND SHUTTER SYNCHRONIZATION. The shutter of the 197A may be actuated from a remote source. This function occurs when the remote source closes a circuit between the REMOTE SHUTTER jacks. When this feature is used, there is a mechanical delay between the time that the signal is received and the time that the shutter is actually open. The delay time is as follows (approximately):

5 ms shutter starts to open
8.5 ms shutter is half open
12 ms shutter fully open

3-32. The SHUTTER SYNC jacks provide a closed circuit when the shutter is actuated. This feature permits synchronization of other equipment with the shutter action. For example, the single sweep action of the oscilloscope could be triggered through this switch action. However, the mechanical delay in actual shutter opening as described above would have to be considered.

3-33. EXTERNAL GRATICULE CONSIDERATIONS.

3-34. Several problem areas must be considered when attempting to photograph displays on an oscilloscope with external graticule.

3-35. PARALLAX. In the internal graticule CRT, the graticule lines are in the same plane as the phosphor. This arrangement eliminates any parallax between the graticule and the display. With external graticule CRT's, the graticule and phosphor are separated, and parallax enters into the measurement. Two parallax effects, as illustrated in figure 3-3, are present:

a. Parallax caused by the difference between lens viewing angle (B) in figure 3-3 and straight-on viewing angle (A).

b. Parallax caused by the difference between lens viewing angle (B) and eye viewing angle (C).

3-36. Parallax problems can be minimized by making certain that the CRT face is in direct contact with the graticule. If scale measurements are to be made from the photographs, determine the error due to parallax




Figure 3-3. Parallax Effects

and make the necessary corrections when viewing the display before exposure. For maximum accuracy, make scale measurements near the center of the photograph.


3-37. DEPTH-OF-FIELD. An important effect to consider when using an external graticule is depth-of-field, the range of object distances within which the image (formed on the film by the lens) will be in focus. Depth-of-field has an inverse relationship with aperture size; that is, the larger the aperture, the shorter the depth of field. To have both an external graticule and the display in focus at the same time, the aperture should be about $f/5.6$ or smaller (larger f -number). For this reason, separate exposure of the graticule and display is recommended whenever an aperture larger than $f/5.6$ is required.

3.38. FILM DEVELOPING.


3-39. A step-by-step procedure for developing the film is given in figure 3-4. The development time is 10 seconds at 25°C . In general, developing for longer periods will increase contrast, and developing for shorter periods will increase maximum writing rate. At lower temperatures, the development time required will be longer for the same contrast (e.g., approximately 45 seconds are required at 0°C).

NOTE


Prints should be coated as soon as possible after development, using print coater supplied with each film pack.

**STEP 1**


Pull white tab out of camera back.

**STEP 2**

Pull yellow tab out of camera back with even, rapid movement. Do not stop midway, or pull at angle (which could tear print).

**STEP 3**

After 10 seconds, peel print from negative paper. Do not hesitate or let print fall back on negative.

**STEP 4**

Coat print with six or eight overlapping strokes. Film pack box may be used to hold print while coating.

197A-R-3-10-75

Figure 3-4. Film Developing

SECTION IV

PRINCIPLES OF OPERATION

4-1. INTRODUCTION.

4-2. This section describes operation of the Model 197A. Separate discussions are presented for the camera back, lens assembly, shutter-control circuit, and power supply.

4-3. INSTRUMENT DESCRIPTION.

4-4. The 197A consists of three basic assemblies: the camera back, the lens-shutter system and the camera mount. The camera mount holds the lens-shutter system and camera back rigidly in place, providing correct spacing and alignment of the display, lens, and film. The lens-shutter system focuses and controls the amount of light transmitted to the film. The film is contained in the camera back where the development process also takes place.

4-5. CAMERA BACK.

4-6. The 197A uses a camera back manufactured by the Polaroid Land Corporation. The camera back holds the film pack and is mounted to the frame of the 197A. The film-development process is initiated within this unit.

4-7. The film-development process is illustrated in figure 4-1. For simplicity, only one negative and one positive are shown. The pressure plate presses the negative stack firmly against the front of the film-pack cover so that the top negative in the stack lies flat in the film plane. After exposure, the white tab

is pulled. This positions the exposed negative over the top positive of the positive stack. At the same time, the white tab for the next exposure (not shown) appears at the opening, while the yellow tab is advanced through a second opening. Pulling the yellow tab causes the developer reagent pod to rupture when it passes between the pressure rollers. As the film is drawn out of the camera, the reagent spreads in a thin layer between the positive and negative papers and reacts with the chemicals on these papers. The finished photograph is removed by peeling the print from the negative. The print must then be coated for permanence using the coater supplied with the film pack.

4-8. LENS ASSEMBLY.

4-9. The 197A has an $f/1.9$ lens with a focal length of 75 mm (2 in.). The lens is especially corrected for use in oscilloscope photography to give minimum distortion over the full image area, and to give a flat field of focus. It is positioned at the factory to produce a 1:0.9 object-to-image ratio so that the full 10-cm (3.9-in.) wide graticule may be viewed on the 9.7-cm (3.8-in.) film. This is accomplished by making the effective distance from lens to film 0.9 of that from the lens to the display. This distance can be adjusted to give a 1:1 or 1:0.7 ratio. The camera back is also movable on a vertical plane parallel with the lens to shift the image vertically on the film. The multiple exposure detent provides eleven detented positions, each shifting the image about 0.5 cm (0.2 in.) on the film.




Figure 4-1. Camera Back Operation




Figure 4-2. Shutter Control Block Diagram

4-10. SHUTTER.

4-11. Since oscilloscope photograph requires accurate and consistent shutter speeds, the 197A camera has an electronic circuit to control the shutter rather than a conventional mechanical shutter. The shutter control circuit is made up of two circuits: the timing circuit, and the solenoid control circuit. Figure 4-2 is a block diagram of the shutter control circuit. Refer to Section VIII for the schematic.

4-12. TIMING CIRCUIT. The shutter timing is controlled by A2U1, capacitors A2C6 and A2C7, A2U2 and transistor A2Q1. At quiescence (shutter closed), the Q output of A2U2 is low and the \bar{Q} output is high. A2Q1 is switched out of the timing circuit in all shutter speed positions except T (time exposure).

4-13. Closing SHUTTER switch S1 activates A2U2, causing the Q output to switch high, opening the shutter. The Q output remains high until the selected timing capacitor (A2C6 or A2C7) charges sufficiently to reset A2U2. The charging time constant is determined by the selected resistance in A2U1 combined with the selected timing capacitor (A2C6 or A2C7). When A2U2 resets, the Q output switches low (closing the shutter).

4-14. When SHUTTER SPEED switch A2S1 is set to T (time exposure), the collector of transistor A2Q1 is applied to the Rx input of A2U2. Closing SHUTTER switch S1 activates A2U2, causing its Q output to go high (opening the shutter). The high output forward biases A2Q1, causing it to saturate. The near zero voltage on the collector of A2Q1 is applied to the Rx input of A2U2, bypassing the timing network. With the voltage at Rx held low, A2U2 stays in the set condition.

4-15. To reset the timing circuit and close the shutter, SHUTTER switch S1 is closed, providing a 5-volt differentiated spike at the base of A2Q1. When A2Q1 turns off, the Rx input to A2U2 is removed, allowing timing capacitor A2C7 to finish charging. When A2C7 finishes charging, A2U2 resets, causing its Q output to go low. The low is applied through A1R3 to A2Q1, keeping it turned off.

4-16. SHUTTER ACTUATION. At quiescence (shutter closed), the Q output from A2U2 is low and keeps solenoid control A1Q1/Q2 turned off. Closing SHUTTER switch S1 causes the Q output to A2U2 to go high and saturates A1Q1/Q2. When A1Q1/Q2 saturates, rotary solenoid L1 activates (opening the shutter) and draws the stored charge from capacitor A1C4.

A1C4 assures fast, positive initial actuation of the rotary solenoid. After the solenoid is activated, the power supply provides the sustaining current to keep it activated.

4-17. When the timing circuit resets, solenoid control A1Q1/Q2 turns off. With no sustaining current, rotary solenoid L1 is mechanically closed by internal spring action.

4-18. Before the shutter can be actuated again, it is necessary for A1C4 to charge to a maximum. The charging time is determined by A1R3 and A1C4 (about 2 seconds).

4-19. Rotary solenoid L1 also has a set of relay contacts S2. These contacts close and open at the same time that the shutter closes and opens. S2 provides the shutter sync contact closure to SHUTTER SYNC jack J2.

4-20. POWER SUPPLY.

4-21. The 197A has three unregulated power supplies and one regulated power supply. Power transformer T1 has two secondary windings. The first winding provides 6.5 V which is applied to capacitors A1C1 and A1C2 and diodes A1CR1 and A1CR2 (a voltage doubler). This circuit converts the 6.5 V to +10.5 V.

4-22. The second winding output is applied to a full-wave bridge rectifier, consisting of diodes A1CR5 through A1CR8. The output of the rectifier provides +12 V to voltage doubler, consisting of capacitor A1C3 and diodes A1CR3 and A1CR4. The output of the voltage doubler is +37 Vdc (under load this drops to approximately +20 Vdc).

4-23. The regulated power supply uses the +10.5 V power source and regulates at +5 Vdc through A2VR1 in the base circuit of common-base transistor A2Q2.

SECTION V

PERFORMANCE CHECK AND ADJUSTMENTS

5-1. INTRODUCTION.

5-2. This section contains procedures for checking Model 197A performance and for making necessary adjustments.

5-3. PERFORMANCE CHECK.

5-4. The performance check verifies that the 197A is operating within the specifications as stated in table 1-1. This check may be used as an incoming quality control check, as a periodic operational check, or after repairs have been made.

5-5. SHUTTER OPERATION. The following procedure verifies shutter operation.

- a. Connect power to the 197A.
- b. Set SHUTTER SPEED selector switch to T.
- c. Press SHUTTER control bar and visually verify that shutter opens. (It may be necessary to open camera back and observe shutter action through camera.)
- d. Press SHUTTER control bar and verify that shutter closes.

5-6. LIGHT LEAKAGE. Check for light leakage in the 197A as follows:

- a. Mount camera on oscilloscope and apply power.

- b. Ensure that there is no display on oscilloscope.
- c. Set SHUTTER SPEED selector switch to 1 second.
- d. Set LENS f/NO. control to 1.9.
- e. Press SHUTTER control bar and develop resulting photograph. Resulting print should be completely black.


NOTE

If light leakage occurs, refer to Section VIII for possible causes.

5-7. ADJUSTMENTS.

5-8. There are no electrical adjustments for Model 197A. Procedures for two of the three mechanical adjustments, focus and reduction ratio, are given in Section III. The other mechanical adjustment is calibration of the LENS f/NO. control and is performed as follows:

- a. Rotate LENS f/NO. control fully counter-clockwise.
- b. Loosen two knob setscrews and position knob so that pointer is aligned with calibration mark below 1.9 position.
- c. Tighten knob setscrews.



197A-002-10-75

197A Exploded View

SECTION VI

REPLACEABLE PARTS

6-1. INTRODUCTION.

6-2. This section contains information for ordering replacement parts. The abbreviations used in the parts list are described in Table 6-1. Table 6-2 lists the parts in alphanumeric order by reference designator and includes the manufacturer and manufacturer's part number. Table 6-3 contains the list of manufacturers' codes.

6-3. ORDERING INFORMATION.

6-4. To obtain replacement parts from Hewlett-Packard, address order or inquiry to the nearest Hewlett-Packard Sales/Service Office and supply the following information:

- a. Instrument model and serial number.
- b. HP Part Number of item(s).
- c. Quantity of part(s) desired.
- d. Reference designator of part(s).

6-5. To order a part not listed in the table, provide the following information:

- a. Instrument model and serial number.
- b. Description of the part, including function and location in the instrument.
- c. Quantity desired.

Table 6-1. Abbreviations for Replaceable Parts List

A	= ampere(s)	GRD	= ground(ed)	NPO	= negative positive zero (zero temperature coefficient)	RWV	= reverse working voltage
ASSY	= assembly						
BD	= board(s)	H	= henry(ies)	NPN	= negative-positive-negative	S-B	= slow-blow
BH	= binder head	HG	= mercury	NSR	= not separately replaceable	SCR	= silicon controlled rectifier
BP	= bandpass	HP	= Hewlett-Packard			SE	= selenium
		HZ	= hertz			SEC	= second(s)
C	= centi (10^{-2})	IF	= intermediate freq.	OBD	= order by description	SECT	= section(s)
CAR	= carbon	IMPG	= impregnated	OH	= oval head	SI	= silicon
CCW	= counterclockwise	INCD	= incandescent	OX	= oxide	SIL	= silver
CER	= ceramic	INCL	= include(s)			SL	= slide
CMO	= cabinet mount only	INS	= insulation(ed)	P	= peak	SP	= single pole
COAX	= coaxial	INT	= internal	PC	= printed (etched) circuit(s)	SPL	= special
COEF	= coefficient			PF	= picofarads	ST	= single throw
COMP	= composition	K	= kilo (10^3)	PHL	= Phillips	STD	= standard
CONN	= connector(s)	KG	= kilogram	PIV	= peak inverse voltage(s)	TA	= tantalum
CRT	= cathode-ray tube	LB	= pound(s)	PNP	= positive-negative-positive	TD	= time delay
CW	= clockwise	LH	= left hand	P/O	= part of	TFL	= teflon
D	= deci (10^{-1})	LIN	= linear taper	PORC	= porcelain	TGL	= toggle
DEPC	= deposited carbon	LOG	= logarithmic taper	POS	= position(s)	THYR	= thyristor
DP	= double pole	LPF	= low-pass filter(s)	POT	= potentiometer(s)	TI	= titanium
DT	= double throw	LVR	= lever	P-P	= peak-to-peak	TNLDIO	= tunnel diode(s)
				PRGM	= program	TOL	= tolerance
ELECT	= electrolytic	M	= milli (10^{-3})	PS	= polystyrene	TRIM	= trimmer
ENCAP	= encapsulated	MEG	= mega (10^6)	PWV	= peak working voltage	U	= micro (10^{-6})
EXT	= external	MET FILM	= metal film			V	= volts
		MET OX	= metal oxide	RECT	= rectifier(s)	VAR	= variable
F	= farad(s)	MFR	= manufacturer	RF	= radio frequency	VDCW	= dc working volt(s)
FET	= field-effect transistor(s)	MINAT	= miniature	RFI	= radio frequency interference		
FH	= flat head	MOM	= momentary	RH	= round head or right hand	W	= watt(s)
FIL H	= fillister head	MTG	= mounting			W/	= with
FXD	= fixed	MY	= mylar	RMO	= rack mount only	WIV	= working inverse voltage
				RMS	= root mean square	W/O	= without
G	= giga (10^9)	N	= nano (10^{-9})			WW	= wirewound
GE	= germanium	N/C	= normally closed				
GL	= glass	NE	= neon				
		N/O	= normally open				




Figure 6-1. Model 197A Exploded View

Table 6-2. Replaceable Parts

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1	00195-66505	1	OUTPUT CIRCUIT BOARD ASSY	28480	00195-66505
A1C1	0180-0104	1	C:FXD ELECT 200 UF +75-10% 15VDCW	56289	300207G015DF4-DSM
A1C2	0180-0094	1	C:FXD ELECT 100 UF +75-10% 25VDCW	56289	300107G025DD2-DSM
A1C3	0180-0141	1	C:FXD ELECT 50 UF +75-10% 50VDCW	56289	300506G050DD2-DSM
A1C4	0180-1784	1	C:FXD ELECT 1000 UF +75-10% 40VDCW	28480	0180-1784
A1C5	0180-0045	1	C:FXD AL ELECT 20 UF +75-10% 25VDCW	56289	300206G025CB2-DSM
A1CR1	1901-0045	10	DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR2	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR3	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR4	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR5	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR6	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR7	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR8	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR9	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1CR10	1901-0045		DIODE:SILICON 0.75A 100PIV	04713	SR1358-7
A1Q1	1854-0053	2	TSTR:SI NPN	80131	2N2218
A1Q2	1854-0072	1	TSTR:SI NPN	80131	2N3054
A1Q3	1854-0071	3	TSTR:SI NPN(SELECTED FROM 2N3704)	28480	1854-0071
A1Q4	1854-0071		TSTR:SI NPN(SELECTED FROM 2N3704)	28480	1854-0071
A1Q5	1853-0012	1	TSTR:SI PNP	80131	2N2904A
A1R1	0684-1011	1	R:FXD COMP 100 OHM 10% 1/4W	01121	CB 1011
A1R2	0687-1211	1	R:FXD COMP 120 OHM 10% 1/2W	01121	EB 1211
A1R3	0761-0037	2	R:FXD MET OX 390 OHM 5% 1W	28480	0761-0037
A1R4	0687-4701	1	R:FXD COMP 47 OHM 10% 1/2W	01121	EB 4701
A1R5	0757-0470	1	R:FXD MET FLM 162K OHM 1% 1/8W	28480	0757-0470
A1R6	0684-3331	1	R:FXD COMP 33K OHM 10% 1/4W	01121	CB 3331
A1R7	0684-4721	1	R:FXD COMP 4700 OHM 10% 1/4W	01121	CB 4721
A1R8	0687-2711	1	R:FXD COMP 270 OHM +/-10% 1/2W	01121	EB 2711
A1R9	0698-3605	1	R:FXD MET OX 15 OHM 5% 2W	28480	0698-3605
A1VR1	1902-0026	1	DIODE BREAKDOWN:36.5V 10%	28480	1902-0026
A2	00197-66504	1	TIMING CIRCUIT BOARD ASSY	28480	00197-66504
A2C1	0150-0023	1	C:FXD CER 2000 PF 20% 1000VDCW	56289	20C295A2-CDH
A2C2	0160-0168	1	C:FXD MY 0.1 UF 10% 200VDCW	56289	192P10492-PTS
A2C3	0160-3451	2	C:FXD CER 0.01 UF +80-20% 100VDCW	56289	C0238101F103ZS25-CDH
A2C4	0160-3451		C:FXD CER 0.01 UF +80-20% 100VDCW	56289	C0238101F103ZS25-CDH
A2C5	0160-0820	1	C:FXD CER 0.05 UF +80-20% 25VDCW	72982	5855 Y5U 503Z
A2C6	0180-0116	1	C:FXD TA ELECT 6.8UF 10% 25VDCW	56289	150D685X9035B2-DYS
A2C7	0180-2358	1	C:FXD TANT 150 UF 5% 6VDCW	56289	150D157X5006R2
A2CR1	1910-0016	2	DIODE:GERMANIUM 100MA/0.85V 60PIV	93332	02361
A2CR2	1910-0016		DIODE:GERMANIUM 100MA/0.85V 60PIV	93332	02361
A2CR3	1910-0016		DELETED		
A2CR4	1910-0016		DELETED		
A2CR5	1910-0016		ROLLER:DETENT	28480	01840-22502
A2CR6	01840-22502	1	TSTR:SI NPN(SELECTED FROM 2N3704)	28480	1854-0071
A2C1	1854-0053		TSTR:SI NPN	80131	2N2218
A2R1	0684-1001	1	R:FXD COMP 10 OHM 10% 1/4W	01121	CB 1001
A2R2	0684-1051	1	R:FXD COMP 1 MEGOHM 1% 1/4W	01121	CB 1051
A2R3	0757-0472	1	R:FXD MET FLM 200K OHM 1% 1/8W	28480	0757-0472
A2R4	0761-0037		R:FXD MET OX 390 OHM 5% 1W	28480	0761-0037
A2U1	1810-0220	1	RESISTIVE NETWORK: THIN FILM	28480	1810-0220
A2U2	1820-0261	1	IC:TTL MONO-STABLE MULTIVIBRATOR	01295	SN74121N
A2VR1	1802-3104	1	DIODE: BREAKDOWN 5.62V 5%	04713	SZ10939-110
A2XU2	1200-0441	1	SOCKET:IC 14 PIN MINIATURE	28480	1200-0441

See Introduction to this section for ordering information

Table 6-2. Replaceable Parts

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1	00195-66505		OUTPUT CIRCUIT BOARD ASSY	28480	00195-66505
A2	00197-66504		TIMING CIRCUIT BOARD ASSY	28480	00197-66504
F1	2110-0064	1	F: 0.125 A 125V SLO-BLO	28480	2110-0064
F1	2110-0311	1	F: 0.062 A 250V SLO-BLO	71400	MDL-1/16
H1	2200-0159	17	SCREW-MACH 4-40 .25-IN-LG 82-DEG FL-HD	28480	2200-0159
H2	2260-0002	12	NUT-HEX-DBL CHAM 4-40 THD .062 THK	28480	2260-0002
H3	0624-0073	4	SCREW-TPG 6-32 .312-IN-LG PAN-HD	28480	0624-0073
H4	0624-0074	4	SCREW-TPG 6-32 .375-IN-LG PAN-HD	28480	0624-0074
H5	0510-0956	2	RING: RETAINING 0.188-IN SHAFT	79136	5133-18-MD
H6	2510-0118	2	SCREW-MACH 8-32 100-DEG FL-HD	28480	2510-0118
H7	0520-0161	4	SCREW-MACH 2-56 .312-IN-LG 82-DEG FL-HD	28480	0520-0161
H8	2200-0157	1	SCREW-MACH 4-40 .438-IN-LG FIL-HD	28480	2200-0157
H9	3050-0105	6	WASHER-FL MTLCL NO. 4 .125-IN-ID .281-IN-OD	28480	3050-0105
H10	2190-0030	8	WASHER-LK HLCL NO. 4 .115-IN-ID .173-IN-OD	28480	2190-0030
H11	3050-0002	1	WASHER-FL MTLCL NO. 10 .203-IN-ID .438-IN-OD	28480	3050-0002
H12	2200-0165	4	SCREW-MACH 4-40 .25-IN-LG 82-DEG FL-HD	28480	2200-0165
H13	0510-0015	1	RETAINER, RING, .125 DIA, CAD PLT STL	79136	5133-12-S-MD-R
H14	2200-0160	10	SCREW-MACH 4-40 .125-IN-LG PAN-HD	28480	2200-0160
H15	0520-0160	4	SCREW-MACH 2-56 .25-IN-LG 82-DEG FL-HD	28480	0520-0160
H16	2200-0151	1	SCREW-MACH 4-40 .75-IN-LG PAN-HD	28480	2200-0151
H17	3050-0066	1	WASHER-FL MTLCL NO. 6 .147-IN-ID .375-IN-OD	28480	3050-0066
H18	2190-0018	11	WASHER-LK HLCL NO. 6 .141-IN-ID .269-IN-OD	28480	2190-0018
H19	2260-0001	6	NUT-HEX-DBL CHAM 4-40 THD .094-THK	28480	2260-0001
H20	2200-0143	1	SCREW-MACH 4-40 .375-IN-LG PAN-HD	28480	2200-0143
H21	2190-0037	1	WASHER-LK INTL T NO. 1/2 .512-IN-ID .789-IN-OD	78189	1224-08
H22	2200-0155	2	SCREW-MACH 4-40 1-IN-LG PAN-HD	28480	2200-0155
H23	2360-0292	10	SCREW-MACH 6-32 .312-IN-LG 100-DEG FL HD	28480	2360-0292
H24	2360-0003	8	SCREW-MACH 6-32 .25-IN-LG RD-HD	28480	2360-0003
H25	2360-0113	6	SCREW-MACH 6-32 .25-IN-LG PAN-HD	28480	2360-0113
H26	2200-0155	2	SCREW-MACH 4-40 1-IN-LG PAN-HD	28480	2200-0155
H27	2190-0469	3	WASHER-LK INTL T NO. 4 .116-IN-ID .265-IN-OD	78189	1704-00-00-4012
H28	2200-0170	8	SCREW-MACH 4-40 .625-IN-LG 82-DEG FL-HD	28480	2200-0170
H29	2950-0006	8	NUT-HEX-DBL CHAM 1/4-32-THD .094-THK	73734	9000
H30	0360-1251	5	TERMINAL, SLDR LUG, 12 SCR, .25/.085 ID	79963	7A-H-1/4
H31	3030-0253	2	SCREW-SKT HD CAP 4-40 .25-IN-LG HEX-REC	28480	3030-0253
H32	0510-0166	1	RETAINER, RING, .156 DIA, CAD PLT STL	97464	1000-15-ST-CD
H33	0510-0715	1	RETAINER, RING, .188 DIA, CAD PLT STL	97464	1001-18-ST-CD
H34	0510-0091	2	RETAINER, RING, .25 DIA, CAD PLT STL	97464	2000-25-ST-CD
H35	0380-0022	2	SPACER-RND .375-LG .128-ID .19 OD STL	76854	3457-424
H36	0380-0411	3	SPACER-RND .5-LG .114-ID .154 OD STL	76854	8960-432
H37	1480-0012	1	PIN-ROL .078-BY-.250 IN	28480	1480-0012
H38	1480-0310	1	PIN-GRV .062-BY-.438 IN	28480	1480-0310
H39	2200-0163	3	SCREW-MACH 4-40 .375-IN-LG TR-HD SLT-REC	28480	2200-0163
H40	2200-0139	10	SCREW-MACH 4-40 .25-IN-LG PAN-HD	28480	2200-0139
H41	2360-0178	2	SCREW-MACH 6-32 .125-IN-LG BDG-HD	28480	2360-0178
H42	2680-0115	2	SCREW-MACH 10-32 .375-IN-LG 100-DEG	28480	2680-0115
H43	3050-0179	2	WASHER-FL MTLCL NO. 10 .203-IN-ID .75-IN-OD	28480	3050-0179
H44	2190-0011	2	WASHER-LK INTL T NO. 10 .195-IN-ID .381-IN-OD	78189	1910-00
H45	2820-0002	2	NUT-HEX-DBL CHAM 10-32-THD .094-THK	28480	2820-0002
H46	2200-0720	6	SCREW-MACH 4-40 .188-IN-LG 82-DEG FL-HD	28480	2200-0720
H47	2200-0752	2	SCREW-MACH 4-40 .125-IN-LG 82-DEG FL-HD	28480	2200-0752
H48	2360-0179	2	SCREW-MACH 6-32 .625-IN-LG BDG-HD	28480	2360-0179
J1	1251-4068	2	CONNECTOR: BANANA JACK	28480	1251-4068
J2	1251-4068		CONNECTOR: BANANA JACK	28480	1251-4068
J3			NSR: PART OF MP11		
L1	5080-0471	1	SOLENOID: ROTARY	28480	5080-0471
MP1	4320-0019	1	MASK: FACE	28480	4320-0019
MP2	00197-44101	1	COVER: END, HOOD TOP	28480	00197-44101
MP3	00197-44102	1	COVER: END, HOOD BOTTOM	28480	00197-44102
MP4	00197-44901	1	DOOR: VIEWING HOOD	28480	00197-44901
MP5	1460-0279	1	SPRING: TORSION	00000	08D
MP6	00195-00101	1	HOOD: VIEWING, OLIVE GRAY	28480	00195-00101
MP6	00197-00101	1	HOOD: VIEWING, BLUE GRAY (OPT X95)	28480	00197-00101
MP7	1440-0035	1	HANDLE: CARRYING 7-13/16" LG	12136	7835-SPECIAL
MP8	00197-44702	1	SEAL: LIGHT	28480	00197-44702
MP9	00197-01207	1	BRACKET: HOOD FRONT	28480	00197-01207
MP10	00195-01201	1	BRACKET: HOOD REAR	28480	00195-01201
MP11	00197-64101	1	COVER: LEFT SIDE: OLIVE GRAY (INCLUDES J3)	28480	00197-64101
MP11	00197-64102	1	COVER: LEFT SIDE: BLUE-GRAY OPTION X95 (INCLUDES J3)	28480	00197-64102
MP12	00197-01209	1	BRACKET: MOUNTING	28480	00197-01209
MP13	00197-04107	1	CUSHION, FELT, T-SHAPE (USED ON MP36)	28480	00197-04107
MP14	9300-0081	4 FT	RIBBON-VELVET (USED ON MP39)	28480	9300-0081
MP15	9300-0070	1 FT	RIBBON-VELVET (USED ON MP41)	28480	9300-0070
MP16	00195-04110	1	COVER: OUTPUT BOARD	28480	00195-04110
MP17	00197-69502	1	FRAME: MOUNTING	28480	00197-69502
MP18	00197-27401	1	BUTTON: LATCH	28480	00197-27401
MP19	1460-0278	1	SPRING: COMPRESSION 0.560" LG	00000	08D
MP20	00197-25001	1	LATCH: SWING AWAY	28480	00197-25001
MP21	0370-0190	1	KNOB: ROUND BLACK 0.187" DIA SHAFT	28480	0370-0190
MP22	00197-23704	1	SHAFT: MOUNTING LOCK	28480	00197-23704

See introduction to this section for ordering information

Table 6-2. Replaceable Parts (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
MP23	00197-22408	1	GEAR:WORM	28480	00197-22408
MP24	00197-22410	1	GEAR:WORM 48 PITCH	28480	00197-22410
MP25	00197-69503	1	LEVER:MOUNTING LOCK	28480	00197-69503
MP26	00197-04701	1	GASKET:MOUNTING	28480	00197-04701
MP27	00197-01205	1	RETAINER:MOUNTING, LEFT HAND	28480	00197-01205
MP28	00197-01206	1	RETAINER:MOUNTING, RIGHT HAND	28480	00197-01206
MP29	00197-04801	2	WIPER:MOUNT	28480	00197-04801
MP30	00197-04702	1	GASKET:WIPER, LEFT HAND	28480	00197-04702
MP31	00197-04704	1	GASKET:WIPER, RIGHT HAND	28480	00197-04704
MP32	00197-05101	1	HINGE:SWING AWAY	28480	00197-05101
MP33	00197-62002	1	ASSY:FRAME FRONT	28480	00197-62002
MP34	00197-62001	1	ASSY:FRAME REAR	28480	00197-62001
MP35	00197-20501	2	TRIM:CAMERA	28480	00197-20501
MP36	00197-00105	1	PLATE:BOTTOM	28480	00197-00105
MP37	00197-60601	1	ASSY:BELLOWS	28480	00197-60601
MP38	00197-40601	1	SEAL:LIGHT	28480	00197-40601
MP39	00197-22001	1	PLATE:DETENT	28480	00197-22001
MP40	00197-64301	1	ASSY:DETENT	28480	00197-64301
MP41	00197-09101	4	SPRING:LEFT DETENT	28480	00197-09101
MP42	00197-05002	1	LATCH:DETENT	28480	00197-05002
MP43	0370-0918	1	BUTTON:DETENT	28480	0370-0918
MP44	1460-0277	1	WIREFORM	00000	0BD
MP45	10353-60001	1	ASSY:CAMERA BACK	28480	10353-60001
MP46	00197-64701	1	ASSY:SHUTTER BOARD	28480	00197-64701
MP47	00197-41703	2	SUPPORT:FRONT	28480	00197-41703
MP48	00197-23702	2	SHAFT:CARRIAGE	28480	00197-23702
MP49	00197-41704	1	SUPPORT LEFT HAND REAR	28480	00197-41704
MP50	00197-41705	1	SUPPORT:RIGHT HAND REAR	28480	00197-41705
MP51	00197-22403	2	GEAR:CARRIAGE DRIVE	28480	00197-22403
MP52	00197-23705	1	SHAFT:CARRIAGE LOCK	28480	00197-23705
MP53	00197-41204	1	CLAMP:CARRIAGE LOCK	28480	00197-41204
MP54	00197-22407	1	SCREW:CARRIAGE CLAMP	28480	00197-22407
MP55	0570-0164	1	SCREW:REDUCTION RATIO	00000	0BD
MP56	00197-48801	1	GROMMET	28480	00197-48801
MP57	00197-04106	1	COVER:BOTTOM	28480	00197-04106
MP58	1000-0226	1	PLATE:FOCUS	28480	1000-0226
MP59			DELETED		
MP60			DELETED		
MP61			DELETED		
MP62	00197-04111	1	COVER:RIGHT SIDE, BLUE GRAY (OPT X95)	28480	00197-04111
MP62	00197-04115	1	COVER:RIGHT SIDE, OLIVE GRAY	28480	00197-04115
MP63	00197-01208	1	BRACKET:FRONT MOUNTING, RIGHT SIDE	28480	00197-01208
MP64	00197-01210	1	BRACKET:PINION	28480	00197-01210
MP65	00197-04703	1	SUPPORT:PINION	28480	00197-04703
MP66	0400-0068	1	BUSHING:SNAP-IN FOR 1/4" DIA SHAFT	96881	4L1-FF
MP67	00197-01201	1	BRACKET:GEAR	28480	00197-01201
MP68	0400-0067	3	BUSHING:SNAP-IN FOR 3/16" DIA SHAFT	96881	3L1-FF
MP69	00197-22405	1	SHAFT:SPLINED	28480	00197-22405
MP70	00197-22401	1	GEAR:PINION	28480	00197-22401
MP71	00197-23701	1	SHAFT:F-DRIVE	28480	00197-23701
MP72	00197-22402	1	GEAR:BEVEL	28480	00197-22402
MP73	00197-01202	2	BRACKET:BEZEL RETAINER	28480	00197-01202
MP74	00197-04113	1	COVER:TIMING BOARD	28480	00197-04113
MP75	00197-00206	1	PANEL:CONTROL	28480	00197-00206
MP76	00197-22201	1	BEZEL:CONTROL PANEL	28480	00197-22201
MP77			DELETED		
MP78	00197-47402	1	LEVER:SHUTTER RELEASE	28480	00197-47402
MP79	0370-0133	1	KNOB:SKIRTED FOR 0.250" DIA SHAFT	28480	0370-0133
MP80	0370-0077	1	KNOB:SKIRTED BAR FOR 0.250" DIA SHAFT	28480	0370-0077
MP81	00197-27402	1	KNOB:FOCUS	28480	00197-27402
MP82	00197-65001	1	LOCK:FOCUS	28480	00197-65001
MP83	00197-47401	1	BUTTON:FOCUS LOCK	28480	00197-47401
MP84	00197-69501	1	ASSY:SHUTTER AND IRIS (INCLUDES L1)	28480	00197-69501
MP85	00197-22005	1	COVER:SHUTTER SOLENOID	28480	00197-22005
MP86	00197-22404	1	GEAR:IDLER	28480	00197-22404
MP87	00197-21702	1	BUSHING:GEAR	28480	00197-21702
MP88	1000-0702	1	LENS:F/1.9 75 MM	28480	1000-0702
MP89			DELETED		
MP90			DELETED		
MP91			DELETED		
MP92			DELETED		
MP93	00197-41002	1	FOOT:CENTER	28480	00197-41002
MP94	00197-41004	1	FOOT:LEFT	28480	00197-41004
MP95	00197-41003	1	FOOT:RIGHT	28480	00197-41003
MP96	00197-41001	1	FOOT:LEVER	28480	00197-41001
MP97	00197-00207	1	PANEL:SUB-POWER	28480	00197-00207
MP98	5020-0568	1	RETAINER:MOUNTING, FOR OPTIONAL USE WITH HP 180-SERIES RECTANGULAR OSCILLOSCOPE BEZELS, REPLACES MP27 AND MP28.	28480	5020-0568
MP99	00197-23707	1	SHAFT:CAMERA SW	28480	00197-23707
MP100			DELETED		
MP101	3130-1390	1	ROTOR ASSY:MALE	28480	3130-1390

See introduction to this section for ordering information

Table 6-2. Replaceable Parts (Cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
MP102	3130-1391	1	ROTOR ASSY:FEMALE	28480	3130-1391
MP103	0510-1101	1	RING:RETAINING FOR MP101 AND MP102	28480	0510-1101
S1	3101-0200	1	SWITCH:SENSITIVE SPOT MINIATURE (SHUTTER)	95146	V3-15
S2	00197-44801	1	SWITCH:SYNC CONTACT	28480	00197-44801
T1	9100-3269	1	TRANSFORMER:POWER	28480	9100-3269
W1	8120-1348	1	CABLE ASSY:POWER, DETACHABLE	28480	8120-1348
W1P1			NSR PART OF W1		
W1P2			NSR PART OF W1		
W2	00197-61605	1	CABLE RIBBON	28480	00197-61605
XF1	1400-0084	1	FUSEHOLDER:EXTRACTOR POST TYPE	75915	342014

Table 6-3. List of Manufacturers' Codes

MFR NO.	MANUFACTURER NAME	ADDRESS	ZIP CODE
00000	NO M/F DESCRIPTION FOR THIS MFG NUMBER		
01121	U.S.A. COMMON	ANY SUPPLIER OF U.S.A.	
01295	ALLEN BRADLEY CO.	MILWAUKEE, WIS.	53204
04713	TEXAS INSTRUMENTS INC. SEMICONDUCTOR COMPONENTS DIV.	DALLAS, TEX.	75231
08906	MOTOROLA SEMICONDUCTOR PROD. INC.	PHOENIX, ARIZ.	85008
12136	S.E. CO. MINIATURE LAMP DEPT.	CLEVELAND, OHIO	44112
28480	PHILADELPHIA HANDLE CO.	CAMDEN, N.J.	08103
56289	HEWLETT-PACKARD COMPANY	PALO ALTO, CALIF.	94304
70903	SPRAGUE ELECTRIC CO.	N. ADAMS, MASS.	01247
71341	BELDEN CORP.	CHICAGO, ILL.	60644
72765	BOSTON GEAR WORKS DIV N. AMERICAN ROCKWELL CORP.	QUINCY, MASS.	02171
72982	DRAKE MFG. CO.	HARWOOD HEIGHTS, ILL.	60656
75915	ERIE TECHNOLOGICAL PROD. INC.	ERIE, PA.	16512
79727	LITTELFUSE INC.	DES PLAINES, ILL.	60016
80131	CONTINENTAL-WIRT ELECTRONICS CORP.	PHILADELPHIA, PA.	19144
82389	ELECTRONIC INDUSTRIES ASSOCIATION	WASHINGTON D.C.	20006
83330	SWITCHCRAFT INC.	CHICAGO, ILL.	60630
93332	SMITH HERMAN H. INC.	BROOKLYN, N.Y.	11207
95145	SYLVANIA ELECTRIC PROD. INC. SEMICONDUCTOR DIV.	WOBURN, MASS.	01801
96881	ALCO ELECT. PROD. INC.	LAWRENCE, MASS.	01843
	THOMSON IND. INC.	MANHASSET, N.Y.	11030

SECTION VII

MANUAL CHANGES

7-1. INTRODUCTION.

7-2. This section contains information required to backdate this manual for a specific instrument. Descriptions of special and selected standard options are also provided in this section.

7-3. MANUAL CHANGES.

Table 7-1. Manual Changes

Serial Prefix	Make Changes
610-	1, 2, 3, 4, 5
730-	2, 3, 4, 5
805-	3, 4, 5
905-	4, 5
913-	4, 5
1203-	5

7-4. This manual applies directly to the instrument having the same serial prefix shown on the manual title page. If the serial prefix of the instrument is not the same as the one on the title page, find your serial prefix in table 7-1 and make the changes to the manual that are listed for that serial prefix. When making changes listed in table 7-1, make the changes with the highest number first. Example: if backdating changes 1, 2, and 3 are required for your serial prefix, do change 3 first, then change 2, and finally change 1. If the serial prefix of the instrument is not listed either on the title page or in table 7-1, refer to the enclosed MANUAL CHANGES sheet for updating information. Also, if a MANUAL CHANGES sheet is supplied, make all indicated ERRATA corrections.

7-5. OPTION 012 WIRING DIAGRAM CHANGE.




Figure 7-1. Option 012 Wiring and Fuse Changes

7-6. Option 012 provides a standard instrument with the power input circuit wired for 230 volts ac operation. If you have ordered a Model 197A/Option 012, see figure 7-1 for wiring and fuse changes.

7-7. MANUAL CHANGES LISTING.

CHANGE 1

Table 7-2,

Delete: R2.

V1: Change to HP Part No. 2140-0064, V:FLUORESCENT ULTRAVIOLET 2W.

Delete: MP91 and MP92.

Figure 7-3,

Delete: R2. Make straight-through connection.

CHANGE 2

Table 7-2,

Delete: CR10 and CR40.

Q11: Change to HP Part No. 1853-0036, Q:SI PNP.

Q41: Change to HP Part No. 1853-0036, Q:SI PNP.

Figure 7-3,

Delete: CR10 and CR40.

CHANGE 3

Table 7-2,

MP11: Change to HP Part No. 00197-04112, COVER: CAMERA L. H.

Add: MP13, HP Part No. 00197-01213, BRACKET, FRONT MOUNTING L. H.

MP15: Change to HP Part No. 0380-0007, SPACER: COVER PC BOARD.

MP62: Change to HP Part No. 00197-04104, COVER: CAMERA R. H.

CHANGE 4

Table 6-2,

Replace with table 7-2.

Figures 8-1 and 8-2,

Replace with figure 7-2.

Figure 8-3,

Replace with figure 7-3.

CHANGE 5

Page 1-1, paragraph 1-11,

Add the following: OPTION 001. This option is a standard instrument with the graticule illumination feature omitted.

Figure 6-1,

Replace with figure 7-4.

Table 6-2,

MP36: Change HP Part No. and Mfr Part No. to 00197-00102; description unchanged.

	A	B	C	D	E	F	
1							1
2							2
3							3
4							4
5							5
6							6
7							7

Figure 7-2. Shutter Control Component Identification




Figure 7-3.
Shutter Control Schematic
7-3




Figure 7-3.
Shutter Control Schematic
7-3





Figure 7-4. Model 197A Exploded View



197A-C-1A

Figure 7-4. Model 197A Exploded View

Add: MP59, HP Part No. 00197-48301; LENS:ULTRA-VIOLET LIGHT; Mfr Code 28480, Mfr Part No. 00197-48301.

Add: MP60, HP Part No. 00197-04110, MASK:ULTRA-VIOLET LIGHT; Mfr Code 28480, Mfr Part No. 00197-04110.

Add: MP61, HP Part No. 00197-20502; REFLECTOR: ULTRAVIOLET LIGHT; Mfr Code 28480, Mfr Part No. 00197-20502.

MP75: Change HP Part No. and Mfr Part No. to 00197-00205; description unchanged.

Add: MP77, HP Part No. 00197-04109; MASK: SWITCH; Mfr Code 28480, Mfr Part No. 00197-04109.

MP79: Change qty to 2.

Add: MP89, HP Part No. 5040-0431; ADAPTER: FILTER; Mfr Code 28480, Mfr Part No. 5040-0431.

Add: MP90, HP Part No. 1000-0011; FILTER:ULTRA-VIOLET; Mfr Code 28480, Mfr Part No. 1000-0011.

Add: MP91, HP Part No. 4330-0433, TUBE:FILTER GLASS, ULTRAVIOLET; Mfr Code 28480, Mfr Part No. 4330-0433.

Add: MP92, HP Part No. 00197-07107, GASKET: ULTRAVIOLET LIGHT; Mfr Code 28480, Mfr Part No. 00197-07107.

Add: MP99, HP Part No. 00197-68101, WINDOW: FILTER, ULTRAVIOLET LIGHT; Mfr Code 28480, Mfr Part No. 00197-68101.

Add: R1, HP Part No. 0698-3605, R:FXD METOX 15 OHM 5% 2W; Mfr Code 28480, Mfr Part No. 0689-3605.

Add: R2, HP Part No. 2100-2049, R:VAR COMP 50K OHM $-10\%+30\%$ 2W; Mfr Code 28480, Mfr Part No. 2100-2049.

Add: S3, HP Part No. 3101-0903, SWITCH:SLIDE DP3T 0.5A 125V AC/DC (GRATILLUM); Mfr Code 79727, Mfr Part No. G128S-0003.

Add: V1, HP Part No. 2140-0254, LAMP:FLUORESCENT ULTRAVIOLET; Mfr Code 08806, Mfr Part No. MF2T6/BL.

Add: XV1, HP Part No. 1450-0147, LAMPHOLDER: BAYONET SOCKET; Mfr Code 72765, Mfr Part No. 4369-051.

Figure 8-3,

Replace with figure 7-5.

Table 7-2. Replaceable Parts for Instrument Serial Prefixes 610- through 913-

Ref Desig	hp Part No.	TQ	Description
A1	00197-66501	1	A: etched circuit board shutter control
A2	00197-61901	1	A: switch shutter speed
C1	0160-0380	1	C: fxd my 0.22 μ f 10% 200vdcw
C2 -			
C9			Not assigned
C10	0150-0121	4	C: fxd cer 0.1 μ f -20% +80% 50vdcw
C11	0150-0081	3	C: fxd cer 0.01 μ f -20% +80% 500vdcw
C12	0160-0962	1	C: fxd my 1 μ f 5% 50vdcw
C13	0150-0081		C: fxd cer 0.01 μ f -20% +80% 50vdcw
C14	0180-0045	1	C: fxd elect al 20 μ f -10% +75% 25vdcw
C15	0150-0050	1	C: fxd cer 1000 pf 600vdcw
C16	0180-0049	3	C: fxd elect al 20 pf -10% +75% 50vdcw
C17	0150-0121		C: fxd cer 0.1 μ f -20% +80% 50vdcw
C18	0180-1782	1	C: fxd elect ta 22 μ f 5% 35vdcw
C19	0180-0101	1	C: fxd elect ta 1.8 μ f 5% 35vdcw
C20 -			
C30			Not assigned
C31	0150-0121		C: fxd cer 0.1 μ f -20% +80% 50vdcw
C32	0180-1784	1	C: fxd elect al 1000 μ f -10% +75% 40vdcw
C33	0180-0058	1	C: fxd elect al 50 μ f -10% +75% 25vdcw
C34 -			
C40			Not assigned
C41	0150-0081		C: fxd cer 0.01 μ f -20% +80% 500vdcw
C42	0180-0216	1	C: fxd elect ta 12 μ f 10% 35vdcw
C43 -			
C45			Not assigned
C46	0180-0049		C: fxd elect al 20 pf -10% +75% 50vdcw
C47	0150-0121		C: fxd cer 0.1 μ f -20% +80% 50vdcw
C48			Not assigned
C49	0170-0024	1	C: fxd my .022 uf 20% 200 vdcw
C50			Not assigned
C51	0180-2281		C: fxd elect al 20 μ f -10% +75% 75 vdcw
CR10	1901-0040	2	CR: si
CR11	1901-0025	16	CR: si
CR12	1901-0025		CR: si
CR13	1901-0025		CR: si
CR14	1901-0025		CR: si
CR15			Not assigned
CR16	1901-0025		CR: si
CR17	1901-0025		CR: si
CR18 -			
CR30			Not assigned
CR31	1901-0025		CR: si
CR32	1901-0049	10	CR: si
CR33	1901-0049		CR: si
CR34	1901-0025		CR: si
CR35	1902-0026	1	CR: avalanche 36.5 v
CR36			Not assigned
CR37	1901-0025		CR: si
CR38	1902-0031	1	CR: avalanche 12.7v
CR39 -			
CR40	1901-0040		CR: si
CR42			Not assigned
CR43	1901-0025		CR: si

Table 7-2. Replaceable Parts for Instrument Serial Prefixes 610- through 913- (Cont'd)

Ref Desig	hp Part No.	TQ	Description		
CR44 & CR45			Not assigned		
CR46	1901-0025		CR: si		
CR47	1901-0025		CR: si		
CR48 - CR50			Not assigned		
CR51	1901-0025		CR: si		
CR52	1901-0025		CR: si		
CR53	1901-0025		CR: si		
CR54	1901-0025		CR: si		
CR55			Not assigned		
CR56	1901-0049		CR: si		
CR57	1901-0049		CR: si		
CR58	1901-0049		CR: si		
CR59	1901-0049		CR: si		
CR60			Not assigned		
CR61	1901-0049		CR: si		
CR62	1901-0049		CR: si		
CR63	1901-0049		CR: si		
CR64	1901-0049		CR: si		
F1	2110-0089	1	F: miniature 1/4 amp		
J1	1251-0202	4	J: banana black (2 required)		
J2	1251-0202		J: banana black (2 required)		
J3	00197-47601	1	J: power receptacle		
K41A	0490-0310	1	K: coil reed relay		
K41B	0490-0313	1	K: switch reed spst		
L1	5080-0471	1	L: rotary solenoid		
Q11	1853-0062	2	Q: si pnp		
Q12	1853-0036	2	Q: si pnp		
Q13 - Q30			Not assigned		
Q31	1850-0098	1	Q: ge pnp		
Q32 - Q40			Not assigned		
Q41	1853-0062		Q: si pnp		
Q42	1853-0036		Q: si pnp		
R2	0757-0394	1	R: fxd metflm 51.1 ohms 1% 1/8w		
R3	0757-0470	1	R: fxd metflm 162k ohms 1% 1/8w		
R4	0757-0458	1	R: fxd metflm 51.1k ohms 1% 1/8w		
R5	0757-0485	1	R: fxd metflm 681k ohms 1% 1/8w		
R6	0757-0468	1	R: fxd metflm 130k ohms 1% 1/8w		
R7	0757-0474	2	R: fxd metflm 243k ohms 1% 1/8w		
R8	0757-0464	1	R: fxd metflm 90.9k ohms 1% 1/8w		
R9	0757-0455	3	R: fxd metflm 36.5k ohms 1% 1/8w		
R10	0757-0438		R: fxd metflm 5110 ohms 1% 1/8w		
R11	0757-0474		R: fxd metflm 243k ohms 1% 1/8w		
R12	0757-0438	2	R: fxd metflm 5110 ohms 1% 1/8w		
R13	0757-0283	1	R: fxd metflm 2000 ohms 1% 1/8w		
R14	0684-1051	1	R: fxd comp 1 megohm 10% 1/4w		
R15	0757-0465	2	R: fxd metflm 100k ohms 1% 1/8w		
R16	0757-0447	2	R: fxd metflm 16.2k ohms 1% 1/8w		
R17	0757-0745	1	R: fxd metflm 4320 ohms 1% 1/4w		

Table 7-2. Replaceable Parts for Instrument Serial Prefixes 610- through 913- (Cont'd)

Ref Desig	hp Part No.	TQ	Description
R18 - R20			Not assigned
R21	0757-0438		R: fxd metflm 5110 ohms 1% 1/8w
R22	0757-0455	1	R: fxd metflm 36.5k ohms 1% 1/8w
R23			Not assigned
R24	0757-0465		R: fxd metflm 100k ohms 1% 1/8w
R25	0757-0481	1	R: fxd metflm 475k ohms 1% 1/8w
R26 - R30			Not assigned
R31	0758-0017	1	R: fxd metox 1500 ohms 5% 1/2w
R32	0758-0057	1	R: fxd metox 5600 ohms 5% 1/2w
R33	0758-0003	3	R: fxd metox 1000 ohms 5% 1/2w
R34	0687-3901	1	R: fxd comp 39 ohms 10% 1/2w
R35	0758-0003		R: fxd metox 1000 ohms 5% 1/2w
R36 & R37			Not assigned
R38	0758-0003		R: fxd metox 1000 ohms 5% 1/2w
R39 & R40			Not assigned
R41	0757-0431	1	R: fxd metflm 2430 ohms 1% 1/8w
R42	0757-0461	1	R: fxd metflm 68.1k ohms 1% 1/8w
R43	0757-0447		R: fxd metflm 16.2k ohms 1% 1/8w
R44	0757-0455		R: fxd metflm 36.5k ohms 1% 1/8w
R45			Not assigned
R46	0811-1626	1	R: fxd ww 4.7 ohms 10% 2w
R47	0811-1627	1	R: fxd ww 12 ohms 10% 2w
R48			Not assigned
R49	2100-2049	1	R: var comp 50k ohms -10% +30% 2w
S1	3101-0200	1	S: pushbutton spdt (shutter)
S2	3100-1314	1	S: rotary 10 position 2 section
S3	3101-0903	1	S: slide dp-3 pos min grat illum
S4	00197-44801	1	S: sync contact assy
T1	9100-1106	1	T: power
TB1	00197-26502	1	TB: u v light
V1	2140-0254	1	V: fluorescent ultraviolet 2w
W1	8120-0078	1	W: power input
W2	00197-61601	1	W: ribbon
XF1			Consists of:
	1400-0110	1	Body: fuseholder
	1400-0111	1	Nut: fuseholder
	1400-0210	1	Cap: fuseholder
XV1	1450-0147	1	XV: bayonet

Table 7-2. Replaceable Parts for Instrument Serial Prefixes 610- through 913- (Cont'd)

Fig 6-1 MP No.	hp Part No.	TQ	Description		
1	4320-0019	1	Mask: face		
2	00197-44101	1	Cover-end: hood top		
3	00197-44102	1	Cover-end: hood bottom		
4	00197-44901	1	Door: viewing hood		
5	1460-0279	1	Spring: door		
6	00197-00101	1	Hood: viewing		
7	1440-0035	1	Handle: carrying (incl attaching hardware)		
8	00197-44701	1	Seal: light		
9	00197-01207	1	Bracket: hood front		
10	00197-01203	1	Bracket: hood rear		
11	00197-04112	1	Cover: camera L. H.		
12	00197-01209	1	Bracket: rear mounting		
14	00197-01211	1	Bracket: power receptacle		
15	0380-0046	2	Spacer: cover pc board		
16	00197-00104	1	Cover: pc board		
17	00197-69502	1	Frame: mounting		
18	00197-27401	1	Button: latch		
19	1460-0278	1	Spring: latch		
20	00197-25001	1	Latch: swing-away		
21	0370-0190	1	Knob: mounting lock		
22	00197-23704	1	Shaft: mounting lock		
23	00197-22408	1	Gear: worm		
24	1430-0104	1	Worm		
25	00197-69503	1	Lever: mounting lock		
26	00197-04701	1	Gasket: mounting		
27	00197-01205	1	Retainer: mounting L. H.		
28	00197-01206	1	Retainer: mounting R. H.		
29	00197-04801	2	Wiper: mount		
30	00197-04702	1	Gasket: wiper L. H.		
31	00197-04704	1	Gasket: wiper R. H.		
32	00197-05101	1	Hinge: swing-away		
33	00197-62002	1	Assy: frame front		
34	00197-62001	1	Assy: frame rear		
35	00197-20501	2	Trim: camera		
36	00197-00102	1	Plate: bottom		
37	00197-60601	1	Assy: bellows		
38	00197-40601	1	Seal: light		
39	00197-22001	1	Plate: detent		
40	00197-64301	1	Assy: detent		
41	00197-09101	4	Spring: leaf detent		
42	00197-05002	1	Latch: detent		
43	00197-47403	1	Button: detent		
44	1460-0277	1	Spring: detent		
45	10353-60001	1	Assy: camera back		
46	00197-64701	1	Assy: shutter board		
47	00197-41703	2	Support: front		
48	00197-23702	2	Shaft: carriage		
49	00197-41704	1	Support: rear L. H.		

Table 7-2. Replaceable Parts for Instrument Serial Prefixes 610- through 913- (Cont'd)

Fig 6-1 MP No.	hp Part No.	TQ	Description
50	00197-41705	1	Support: rear R. H.
51	00197-22403	2	Gear: carriage drive
52	00197-23705	1	Shaft: carriage lock
53	00197-41204	1	Clamp: carriage lock
54	00197-22407	1	Screw: carriage clamp
55	0570-0164	1	Screw: reduction ratio
56	00197-48801	1	Grommet
57	00197-04106	1	Cover: bottom
58	00197-44601	1	Plate: focus
59	00197-48301	1	Lens: ultraviolet light
60	00197-04110	1	Mask: ultraviolet light
61	00197-20502	1	Reflector: ultraviolet light
62	00197-04111	1	Cover: camera R. H.
63	00197-01208	1	Bracket: front mounting R. H.
64	00197-01210	1	Bracket: pinion
65	00197-04703	1	Support: pinion
66	0400-0068	1	Bushing
67	00197-01201	1	Bracket: gear
68	0400-0067	3	Bushing
69	00197-22405	1	Shaft: splined
70	00197-22401	1	Gear: pinion
71	00197-23701	1	Shaft: f-drive
72	00197-22402	1	Gear: bevel
73	00197-01202	2	Bracket: bezel retainer
74	00197-00103	1	Cover: switch
75	00197-00201	1	Panel: control
76	00197-22004	1	Bezel: control panel
77	00197-04109	1	Mask: switch
78	00197-47402	1	Lever: shutter release
79	0370-0133	2	Knob: skirted
80	0370-0077	1	Knob: skirted bar
81	00197-27402	1	Knob: focus
82	00197-65001	1	Lock: focus
83	00197-47401	1	Button: focus lock
84	00197-69501	1	Assy: shutter and iris
85	00197-22005	1	Cover: shutter solenoid
86	00197-22404	1	Gear: idler
87	00197-21702	1	Bushing: gear
88	1000-0702	1	Lens: f/1.9 75 mm
89	5040-0431	1	Adapter: filter
90	1000-0011	1	Filter: ultraviolet
91	4330-0433	1	Sleeve: filter ultraviolet
92	00197-07107	1	Gasket: UV light
93	00197-41002	1	Gasket: foot center
94	00197-41004	1	Gasket: foot left
95	00197-41003	1	Gasket: foot right
96	00197-41001	1	Gasket: foot level
97	00197-00204	1	Panel: sub

Figure 7-5.
Shutter Control Schematic
7-11/(7-12 blank)




Figure 7-5.
Shutter Control Schematic
7-11/(7-12 blank)

SECTION VIII

SCHEMATICS AND TROUBLESHOOTING

8-1. INTRODUCTION.

8-2. This section contains the schematic, repair and replacement information, and component-identification illustrations.

8-3. SCHEMATIC.

8-4. The schematic is drawn to show electronic functions of the circuits.

8-5. All components within the bordered areas of the schematic are physically located on etched circuit boards. Components not physically located on an etched circuit board are shown in the unbordered areas of the schematic. Location of components on assemblies are illustrated on drawings adjacent to the schematic.

8-6. PREVENTIVE MAINTENANCE.

8-7. Preventive maintenance consists of periodic performance checks, mechanical inspection, lubrication, and other services designed to prevent breakdown and failure. Performance checks and adjustments are covered in Section V of this manual. Other preventive maintenance services are covered in the following paragraphs.

8-8. MECHANICAL INSPECTION. Periodically inspect the instrument for damaged components, excess grease, dirt, and corrosion. Look for loose and misaligned parts. Ensure that all screws and fasteners are tight and serviceable.

8-9. Painted surfaces can be cleaned with a commercial, spray-type, window cleaner or with a mild soap and water solution. Excess grease can be removed with a degreaser such as M-180 FREON TF DEGREASER produced by Miller-Stevenson Company.

8-10. Corroded spots are best removed with soap and water. Stubborn residues can best be removed with a fine abrasive. When using abrasives, be careful that fine particles do not fall into the instrument. Such areas should be protected from further corrosion by an application of a silicone resin such as GE DRI-FILM 88.

8-11. CAMERA BACK CLEANING. The entire camera back interior should be inspected and cleaned, if necessary, before installing a new film pack. In partic-

ular, it should be inspected for residue from any developer reagent that may have spilled. The residue should be wiped off carefully with a damp cloth to avoid scratching or spotting subsequent prints. Use a nonmetallic object to dislodge any dried reagent.

8-12. LENS CLEANING. Both lens and filter should be inspected regularly and cleaned as necessary. For cleaning, use lens tissue or, for heavy smudges or grease spots (such as fingerprints), a commercial lens cleaner. When cleaning the lens avoid undue pressure which could affect the lens coating.

8-13. LUBRICATION. Periodic lubrication of the camera is not required. If there is a noticeable binding at any of the points listed in table 8-1, a small amount of lubricant should be applied.

Table 8-1. Camera Lubrication Points

Location	Figure 6-1 MP No.	Recommended Lubricant
Mounting lock worm gear	23, 24	Lubriplate
Carriage shafts (2 places)	48	Graphite powder
Carriage drive gears (2 places)	51	Graphite powder
Carriage lock drive	54, 82	Lubriplate
Reduction ratio screw	55	Lubriplate
Iris drive gears	69, 86	Lubriplate
f/stop bevel gear	70, 71	Lubriplate

8-14. REPAIR AND REPLACEMENT.

8-15. Repair of the Model 197A consists of replacing defective components located during troubleshooting. The following paragraphs provide information on access to instrument components and special servicing information for etched circuit boards.

CAUTION

When replacing components mounted on the stud-welded aluminum studs, i.e., brackets, covers, and pc board, do not tighten nuts to more than 5 inch-pounds torque.

8-16. SIDE PANEL ACCESS. Both side panels can be detached from the camera frame for access to components. When detached, the side panels will lay flat and the frame may be removed and set aside. The panels are, however, still connected together by the ribbon cable which must be removed before complete separation of the panels is achieved. To detach the side panels from the camera frame, proceed as follows:

- a. Remove bottom cover (6 screws).
- b. Remove FOCUS and LOCK knobs (note position of LOCK knob).
- c. Open mounting frame.
- d. Remove three screws on left side (for right hand cover).
- e. Press front of right-hand cover from inside of camera until cover is clear of camera frame, then pull forward to disengage cover from guide pins on rear of frame.

NOTE

Disengage cable grommet from camera frame if panels are to be separated from frame.

- f. Remove three screws (first, third, and fifth) from right side (for left-hand cover).
- g. Press front of left-hand cover from inside of camera until cover is clear of camera frame, then pull forward to disengage cover from guide pins on rear of frame.
- h. Reverse procedure to replace side panels.

CAUTION

When replacing side panels, ensure that splined shaft and iris idler gear are mated correctly.

- i. When side panels are replaced, accomplish LENS f/NO. adjustment as described in Section V.

8-17. SERVICING ETCHED CIRCUIT BOARDS. The etched circuit boards have plated through component holes. This allows components to be removed or replaced by unsoldering or soldering from either side of the board. When removing large components such as potentiometers, rotate the soldering iron tip from lead to lead while applying pressure to the part to lift it from the board. HP Service Note M-20E contains additional information for repair of etched circuit boards.

8-18. When removing a semiconductor, use long-nosed pliers as a heat sink between the device and the

soldering iron. When replacing a semiconductor, ensure sufficient lead length to dissipate the soldering heat by using the same length of exposed lead as used for the original part.

8-19. TROUBLESHOOTING.

WARNING

Read the Safety Summary at the front of this manual before troubleshooting the instrument.

8-20. Troubleshooting the instrument consists of a thorough visual inspection, and then an electrical check if necessary. During the visual inspection, look for loose, broken, or binding mechanical components; loose or discolored electrical components or wiring; or any other similar condition which indicates a source of trouble. Repair any faulty component or connection that is encountered during the visual inspection and check instrument performance before continuing to troubleshoot the instrument.

8-21. If no obvious fault is located during the visual inspection, proceed with the electrical check. Use the block diagram (figure 4-2) and the schematic (figure 8-3) as aids in trouble isolation. Check dc voltages as shown on the schematic to further isolate the problem.

8-22. PRINT QUALITY IMPROVEMENT.

8-23. Most problems encountered in oscilloscope photography involve incorrect control settings or conditions of operation. These problems can often be avoided by closely following the mounting instructions in Section II, and the operating information in Section III. Some of the most common problems are discussed in the following paragraphs.

8-24. LIGHT LEAKAGE. Check for light leakage in the camera as follows:

- a. Mount camera on oscilloscope, and apply power to camera.
- b. Verify that there is no display on oscilloscope.
- c. Set SHUTTER SPEED selector switch to 1 second.
- d. Set LENS f/NO. control to 1.9.
- e. Press SHUTTER control bar and develop resulting photograph.
- f. Resulting print should be completely black.

NOTE

If light leakage occurs, refer to paragraph 8-25 for possible causes.

8-25. FOGGING. Fogging or undesirable light areas over all or part of the print can be caused by many factors. The two main causes are internal (within the oscilloscope) or external light leakage.

8-26. Internal Sources. Many causes of fogging originate in the oscilloscope itself. These problems can become difficult to control, especially when time exposures are required. Some of the most common faults are:

a. Excessive brilliance can cause general "bloom-ing" of the trace which tends to illuminate entire screen. This can be corrected by decreasing display intensity.

b. Orange-yellow light emitted from cathode of un-aluminized CRT can cause fogging on time exposures. A blue filter over the CRT face or camera lens may help reduce this type of fogging.

c. An unblanked oscilloscope can also cause fogging, especially if it is being used for recording transients, since the spot remains visible until a transient occurs. This problem can be minimized by positioning the spot to a point just off display area, or by masking the spot with a small piece of tape.

8-27. External Sources. External light leakage is another common cause of film fogging. Some common sources are:

a. Improper mounting may not permit mounting frame light gasket to seat firmly against bezel.

b. A loose fitting bezel may permit stray light to enter edge of CRT face (or external graticule). Masking edges of bezel will usually solve this problem.

c. Light entering CRT internally through cover perforations of the instrument is more difficult to eliminate. Reduction of ambient light will probably be the most practical solution.

CAUTION

If a black cloth (or any other type of covering) is used over the oscilloscope for reduction of ambient light, do not cut off air circulation to the instrument.

8-28. FILM TEARING. Film damage due to tearing is usually caused by not pulling the yellow tab straight out when advancing the film. The tab should be pulled in a straight line parallel with the long axis of the camera back.

8-29. PRINT IMPERFECTIONS. Dark spots appearing at the same place on successive exposures may be caused by dust on the lens or filter. White spots on the print can be caused by an accumulation of developer residue or foreign matter on the pressure rollers in the camera back. Keeping the lens and inside of the camera back clean will eliminate many imperfections (refer to paragraph 8-11 for cleaning recommendations). A diagonal pattern on all prints indicates that the pressure rollers are worn or damaged.




Figure 8-1. Output Circuit A1 Component Identification

REF DESIG	GRID LOC	REF DESIG	GRID LOC	REF DESIG	GRID LOC	REF DESIG	GRID LOC
C1	C-2	C6	B-3	Q1	A-2	R4	B-4
C2	C-2	C7	B-3	Q2	A-5	VR1	A-4
C3	B-2	CR1	C-3	R1	C-3	U1	E-2
C4	C-3	CR2	B-3	R2	C-2	U2	B-4
C5	A-4	MP1	C-4	R3	B-2	XU2	B-4

Figure 8-2. Timing Circuit A2 Component Identification




Figure 8-3.
Shutter Control Schematic
8-5/(8-6 blank)

SALES & SERVICE OFFICES

UNITED STATES

ALABAMA
8990 Whitesburg Dr. S.E.
P.O. Box 4207
Huntsville 35897
Tel. (205) 861-4591
TWX 810-726-2204
Medical Only
226 W. Valley Ave.
Room 300
Birmingham 35209
Tel. (205) 879-2081/2

ARIZONA
2336 E. Magnolia St.
Phoenix 85034
Tel. (602) 244-1361
TWX 910-951-1331
2424 East Arizon Rd.
Tucson 85706
Tel. (602) 869-4661

ARKANSAS
Medical Service Only
Little Rock 72205
Tel. (501) 664-8773

CALIFORNIA
1430 East Orangehorpe Ave.
Fullerton 92631
Tel. (714) 870-1000
TWX 910-592-1268

3939 Lankershim Boulevard
North Hollywood 91604
Tel. (818) 877-1262
TWX 910-499-2170
6305 Arizona Place
Los Angeles 90045
Tel. (213) 649-2511
TWX 910-328-6147

Los Angeles
Tel. (213) 776-7500

3003 Scott Boulevard
Santa Clara 95050
Tel. (408) 249-7000
TWX 910-336-0516

Ridgcrest
Tel. (714) 446-6165
2220 Watt Ave.
Sacramento 95825
Tel. (916) 482-1463
TWX 910-367-2092

9606 Aero Drive
P.O. Box 23333
San Diego 92123
Tel. (714) 279-3200
TWX 910-335-2000
Calculators Only
601 California St.
San Francisco 94108
Tel. (415) 989-8470

COLORADO
5600 South Ulster Parkway
Englewood 80110
Tel. (303) 771-3455
TWX 910-935-0705

CONNECTICUT
12 Lunar Drive
New Haven 06525
Tel. (203) 389-6551
TWX 710-465-2029

FLORIDA
P.O. Box 24210
2806 W. Oakland Park Blvd.
Fl. Lauderdale 33307
Tel. (305) 731-2020
TWX 510-955-4099

Jacksonville
Medical Service Only
Tel. (904) 725-6333

P.O. Box 13910
6177 Lake Eleanor Dr.
Orlando 32609
Tel. (305) 859-2900
TWX 810-650-0113
21 East Wright St.
Suite 1
Pensacola 32501
Tel. (904) 434-3081

GEORGIA
P.O. Box 28234
450 Interstate North
Atlanta 30328
Tel. (404) 434-4000
TWX 810-766-4890

HAWAII
2875 So. King Street
Honolulu 96814
Tel. (808) 955-4455

ILLINOIS
5500 Howard Street
Skokie 60076
Tel. (312) 677-0400
TWX 910-223-3613
St. Joseph
Tel. (217) 469-2133
INDIANA
7301 North Shadeland Ave.
Indianapolis 46250
Tel. (317) 842-1000
TWX 810-260-1796

IOWA
1902 Broadway
Iowa City 52240
Tel. (319) 338-9466
Night. (319) 338-9467

KANSAS
Derby
Tel. (316) 267-3555

LOUISIANA
P.O. Box 840
3239 Williams Boulevard
Kenner 70062
Tel. (504) 721-6201
TWX 810-955-5524

KENTUCKY
Medical Calculator Only
8003 Troulwood Court
Louisville 40291
Tel. (502) 426-4341

MARYLAND
6707 Whitestone Road
Baltimore 21207
Tel. (301) 944-5400
TWX 710-862-9157

4 Choke Cherry Road
Rockville 20850
Tel. (301) 948-6370
TWX 710-826-9665
710-826-0487

P.O. Box 1648
2 Choke Cherry Road
Rockville 20850
Tel. (301) 948-6370
TWX 710-826-9664

MASSACHUSETTS
32 Hartwell Ave.
Lexington 02173
Tel. (617) 861-8960
TWX 710-326-6904

MICHIGAN
23855 Research Drive
Farmington 48024
Tel. (313) 476-6400
TWX 810-242-2900

MINNESOTA
2400 N. Prior Ave.
Roseville 55113
Tel. (612) 636-0700
TWX 910-563-3734

MISSISSIPPI
Jackson
Medical Service Only
Tel. (601) 982-9363

MISSOURI
11131 Colorado Ave.
Kansas City 64137
Tel. (816) 763-8000
TWX 910-771-2087
148 Weldon Parkway
Maryland Heights 63043
Tel. (314) 567-1455
TWX 910-764-0830

NEBRASKA
Medical Only
11902 Elm Street
Suite 4C
Omaha 68144
Tel. (402) 333-6017

NEW JERSEY
W. 120 Century Rd.
Paramus 07652
Tel. (201) 265-5000
TWX 710-990-4951

NEW MEXICO
P.O. Box 11634
Station E
11300 Lomas Blvd. N.E.
Albuquerque 87123
Tel. (505) 292-1330
TWX 910-989-1185

156 Wyatt Drive
Las Cruces 88001
Tel. (505) 526-2485
TWX 910-983-0550

NEW YORK
6 Automation Lane
Computer Park
Albany 12205
Tel. (518) 458-1550
TWX 710-441-8270
Calculators Only
1251 Avenue of the Americas
Floor 32 - Suite 3296
New York City 10020
Tel. (212) 265-5575

New York City
Manhattan, Bronx
Contact Paramus, NJ Office
Tel. (201) 265-5000
Brooklyn, Queens, Richmond
Contact Woodbury, NY Office
Tel. (516) 921-0300

201 South Avenue
Poughkeepsie 12601
Tel. (914) 454-7330
TWX 510-248-0012
39 Saginaw Drive
Rochester 14623
Tel. (716) 473-9500
TWX 510-253-5981

5858 East Molloy Road
Syracuse 13211
Tel. (315) 455-2486
TWX 710-541-0482

1 Crossways Park West
Woodbury 11797
Tel. (516) 921-0300
TWX 510-221-2168

NORTH CAROLINA
P.O. Box 5188
1923 North Main Street
High Point 27262
Tel. (919) 885-8101
TWX 510-926-1516

OHIO
16500 Sprague Road
Cleveland 44130
Tel. (216) 243-7300
Night. 243-7305
TWX 810-423-9431

330 Progress Rd.
Dayton 45449
Tel. (513) 859-8202
TWX 810-459-1925
1041 Kingsmill Parkway
Columbus 43229
Tel. (614) 436-1041

OKLAHOMA
P.O. Box 32008
Oklahoma City 73132
Tel. (405) 721-0200
TWX 910-830-6862

OREGON
17890 SW Boones Ferry Road
Tualatin 97062
Tel. (503) 620-3350
TWX 910-467-8714

PENNSYLVANIA
111 Zeta Drive
Pittsburgh 15238
Tel. (412) 782-0400
Night. 782-0401
TWX 710-795-3124
1021 8th Avenue
King of Prussia Industrial Park
King of Prussia 19406
Tel. (215) 265-7000
TWX 510-660-2670

SOUTH CAROLINA
6941-O N. Trenholm Road
Columbia 29260
Tel. (803) 782-6493

TENNESSEE
Memphis
Medical Service Only
Tel. (901) 274-7472

Nashville
Medical Service Only
Tel. (615) 244-5448

TEXAS
P.O. Box 1270
201 E. Arapaho Rd.
Richardson 75080
Tel. (214) 231-6101
TWX 910-867-4723

P.O. Box 27409
6300 Westpark Drive
Suite 100
Houston 77027
Tel. (713) 781-6000
TWX 910-881-2645
205 Billy Mitchell Road
San Antonio 78226
Tel. (512) 434-8241
TWX 910-871-1170

UTAH
2160 South 3720 West Street
Salt Lake City 84119
Tel. (801) 487-0715

VIRGINIA
Medical Only
P.O. Box 12778
No. 7 Koger Exec. Center
Suite 212
Norfolk 23502
Tel. (804) 497-1026/7

P.O. Box 9854
2914 Hungary Springs Road
Richmond 23228
Tel. (804) 285-3431
TWX 710-956-0157

WASHINGTON
Bellevue Office Pk.
1203 114th SE
Bellevue 98004
Tel. (206) 454-3971
TWX 910-443-2446

WEST VIRGINIA
Medical Analytical Only
Charleston
Tel. (304) 345-1640

WISCONSIN
9004 West Lincoln Ave.
West Allis 53227
Tel. (414) 541-0550

FOR U.S. AREAS NOT LISTED:
Contact the regional office
nearest you: Atlanta, Georgia
North Hollywood, California
Rockville, Md. (Choke Cherry Rd.)
Maryland, Skokie, Illinois
Their complete addresses
are listed above.

*Service Only

CANADA

ALBERTA
Hewlett-Packard (Canada) Ltd.
11748 Kingsway Ave.
Edmonton T5G 0A5
Tel. (403) 452-3670
TWX 610-631-2431
Hewlett-Packard (Canada) Ltd.
915-42 Avenue S.E. Suite 102
Calgary T2C 1Z1
Tel. (403) 287-1672

BRITISH COLUMBIA
Hewlett-Packard (Canada) Ltd.
837 E. Cordova Street
Vancouver V6A 3R2
Tel. (604) 254-0531
TWX 610-922-5059

MANITOBA
Hewlett-Packard (Canada) Ltd.
513 Century St.
St. James
Winnipeg R3H 0L8
Tel. (204) 785-7581
TWX 610-671-3531

NOVA SCOTIA
Hewlett-Packard (Canada) Ltd.
800 Windmill Road
Dartmouth B3B 1L1
Tel. (902) 469-7820

ONTARIO
Hewlett-Packard (Canada) Ltd.
1785 Woodward Dr.
Ottawa K2C 0P9
Tel. (613) 225-6530
TWX 610-562-8968
Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
Mississauga L4V 1L9
Tel. (416) 678-9430
TWX 610-492-4246

QUEBEC
Hewlett-Packard (Canada) Ltd.
275 Hymus Blvd.
Pointe Claire H9R 1G7
Tel. (514) 697-4232
TWX 610-422-3022
TLX 05-821521 HPCL

Hewlett-Packard (Canada) Ltd.
2376 Galvani Street
Ste-Foy G1H 4G4
Tel. (418) 688-8710

FOR CANADIAN AREAS NOT LISTED:
Contact Hewlett-Packard (Canada)
Ltd. in Mississauga

CENTRAL AND SOUTH AMERICA

ARGENTINA
Hewlett-Packard Argentina
S.A. C.A.
Lavalle 1171-3° Piso
Buenos Aires
Tel. 35-0436 35-0627 35-0341
Telex 912-1009
Cable: HEWPACK ARG

BOLIVIA
Stambuk & Mark (Bolivia) Ltda.
Av. Mariscal Santa Cruz 1342
La Paz
Tel. 40626 53163 52421
Telex 3550014
Cable: BUKMAR

BRAZIL
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Frei Caneca, 1 152-Bela Vista
01307-Sao Paulo-SP
Tel. 288-71-11 287-61-20
287-61-93
Telex 309151/2/3
Cable: HEWPACK Sao Paulo

Hewlett-Packard Do Brasil
I.E.C. Ltda.
Praça Dom Feliciano, 78-B
andar (Sala 806-B)
9000-Porto Alegre-RS
Tel. 25-84-70-DDD (0512)
Cable: HEWPACK Porto Alegre
Hewlett-Packard Do Brasil
I.E.C. Ltda.
Rua Siquiera Campos, 53 4°
andar Copacabana
2000-Rio de Janeiro-GB
Tel. 257-60-94-DDD (021)
Telex 2100 79 HEWPACK
Cable: HEWPACK
Rio de Janeiro

CHILE
Calcagni y Metcalfe Ltda.
Calle Lira 61, Oficina 5
Casilla 2118
Santiago, 1
Tel. 396613
Cable: CALMET

COLOMBIA
Instrumentación
Henrik A. Langebaek & Kier S.A.
Carrera 7 No. 48-59
Apartado Aéreo 6287
Bogotá, 1 D.E.
Tel. 45-78-06 45-55-46
Cable: AARIS Bogotá
Telex: 44400INSTCO

COSTA RICA
Científica Costarricense S.A.
Apartado 10159
San José
Tel. 21-65-13
Cable: GALGUR San José

GUATEMALA
IPESA
Avenida La Reforma 3-48
Zona 9
Guatemala
Tel. 63627 64785
Telex 4192 TELTRO GU

MEXICO
Hewlett-Packard Mexicana.
S.A. de C.V.
Torres Adalid No. 21, 11° Piso
Col. del Valle
Mexico 12 D.F.
Tel. (905) 543-42-32
Telex 017-74-507
Hewlett-Packard Mexicana.
S.A. de C.V.
Ave. Constitución No. 2184
Monterrey, N.L.
Tel. 48-71-32 48-71-84
Nicaragua
Roberto Terán G.
Apartado Postal 689
Edificio Terán
Managua
Tel. 3451 3452
Cable: ROTERAN Managua

PANAMA
Electrónico Balboa, S.A.
P.O. Box 4929
Calle Samuel Lewis
Ciudad de Panama
Tel. 64-2700
Telex 3431103 Curunda
Canal Zone
Cable: ELECTRON Panama
PERU
Compañía Electro Médica S.A.
Ave. Enrique Canaval 312
San Isidro
Casilla 1030
Lima
Tel. 22-3900
Cable: ELMED Lima

PUERTO RICO
San Juan Electronics, Inc.
P.O. Box 5167
Ponce de León 154
Pda. 3-PTA de Tierra
San Juan 00906
Tel. (809) 725-3342 722-3342
Cable: SATRONICS San Juan
Telex: SATRON 3450 332
URUGUAY
Pablo Ferrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel. 40-3102
Cable: RADIUM Montevideo

VENEZUELA
Hewlett-Packard de Venezuela
C.A.
Apartado 50933
Edificio Segre
Tercera Transversal
Los Ruices Norte
Caracas 107
Tel. 35-00-11
Telex 21146 HEWPACK
Cable: HEWPACK Caracas

FOR AREAS NOT LISTED, CONTACT:
Hewlett-Packard
Inter-Americas
3200 Hillview Ave.
Palo Alto, California 94304
Tel. (415) 493-1501
TWX 910-373-1260
Cable: HEWPACK Palo Alto
Telex 034-8300, 034-8493

EUROPE

AUSTRIA
Hewlett-Packard Ges m b H
Handelsk 52 3
P.O. Box 7
A-1205 Vienna
Tel: (0222) 33 66 06 to 09
Cable: HEWPAK Vienna
Telex: 75923 hewpak a

BELGIUM
Hewlett-Packard Benelux
S.A. N.V.
Avenue de Col-Vert 1
(Groenkraslaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex: 23 494 paloben bru

DENMARK
Hewlett-Packard A S
Datavej 52
DK-3460 Birkerød
Tel: (01) 81 66 40
Cable: HEWPAK AS
Telex: 166 40 hp as
Hewlett-Packard A S
Navervej 1
DK-6600 Silkeborg
Tel: (06) 62 71 66
Telex: 166 40 hp as
Cable: HEWPAK AS

FINLAND
Hewlett-Packard Oy
Nahkausuntie 5
P.O. Box 6
SF-00211 Helsinki 21
Tel: 6923031
Cable: HEWPAK OY Helsinki
Telex: 12-15363

FRANCE
Hewlett-Packard France
Quartier de Courtaboeuf
Boite Postale No 6
F-91401 Orsay
Tel: (1) 907 76 25
Cable: HEWPAK Orsay
Telex: 60048
Hewlett-Packard France
Agence Regionale
Chemin des Mouilles
Boite Postale No 12
F-69130 Ecully
Tel: (78) 33 81 25
Cable: HEWPAK Ecully
Telex: 31 617
Hewlett-Packard France
Agence Regionale
Zone Aeronautique
Avenue Clement Ader
F-31770 Colomiers
Tel: (61) 78 11 55
Telex: 51957

Hewlett-Packard France
Agence Regionale
Centre d'aviation generale
F-13721 Aeroport de
Marignane
Tel: (91) 89 12 36
TWX 41770 F
Hewlett-Packard France
Agence Regionale
63, Avenue de Rochester
F-35000 Rennes
Tel: 74912 F
Telex: 74 912 F
Hewlett-Packard France
Agence Regionale
74, Allée de la Robertsau
F-67000 Strasbourg
Tel: (88) 35 23 20 21
Telex: 69141
Cable: HEWPAK STRBG
Medical Calculator Only
Hewlett-Packard France
Agence Regionale
Centre Vauban
201, rue Colbert
Entrée Az
F-59000 Lille
Tel: (20) 51 44 14

GERMAN FEDERAL REPUBLIC
Hewlett-Packard GmbH
Vertriebszentrale Frankfurt
Bernerstrasse 117
Postfach 560 140
D-6000 Frankfurt 56
Tel: (0611) 50 04-1
Cable: HEWPAKSA Frankfurt
Telex: 41 32 49 fra
Hewlett-Packard GmbH
Technisches Büro Boblingen
Herrenbergerstrasse 110
D-7030 Boblingen, Württemberg
Tel: (07031) 66 72 87
Cable: HEPAK Boblingen
Telex: 72 65 739 bbn
Hewlett-Packard GmbH
Technisches Büro Düsseldorf
Vogelsanger Weg 38
D-4000 Düsseldorf
Tel: (0211) 63 80 31-5
Telex: 65 86 533 hpd d
Hewlett-Packard GmbH
Technisches Büro Hamburg
Wendenstrasse 23
D-2000 Hamburg 1
Tel: (040) 24 13 93
Cable: HEWPAKSA Hamburg
Telex: 21 63 032 hph d

Hewlett-Packard GmbH
Technisches Büro Hannover
Mellendorfer Strasse 3
D-3000 Hannover-Kleefeld
Tel: (0511) 55 60 46
Telex: 092 3259
Hewlett-Packard GmbH
Technisches Büro Nürnberg
Hersbruckerstrasse 42
D-8500 Nürnberg
Tel: (0911) 57 10 66
Telex: 623 860
Hewlett-Packard GmbH
Technisches Büro München
Unterhachinger Strasse 28
ISAR Center
D-8012 Ottenbrunn
Tel: (089) 601 30 61-7
Telex: 52 49 85
Cable: HEWPAKSA München
(West Berlin)
Hewlett-Packard GmbH
Technisches Büro Berlin
Keith Strasse 2-4
D-1000 Berlin 30
Tel: (030) 24 90 86
Telex: 18 34 05 hpbm d

GREECE
Kostas Karayannis
18, Ermou Street
GR Athens 126
Tel: 3230-303 Sales SVC
3230-305 Adm. Order Proc.
Cable: RAKAR Athens
Telex: 21 59 62 rkar gr
Hewlett-Packard S.A.
Mediterranean & Middle East
Operations
35 Kolokotroni Street
Platia Kefallionu
GR-Kifissia Athens
Tel: 8080337 8080359
8080429 8018693
Telex: 21 6588
Cable: HEWPAKSA Athens
Analytical Only
INTECO G. Papathanassiou & Co
Marini 17
GR - Athens 103
Tel: 521 915
Cable: INTEKNIKA
Telex: 21 5329 INTE GR
Medical Only
Technomed Hellas Ltd
52, Skoufa Street
GR - Athens 135
Tel: 626 972
Cable: ETALAK Athens
Telex: 21-4693 ETAL GR

IRELAND
Hewlett-Packard Ltd
King Street Lane
Winnemah, Wokingham
GB-Berkshire RG11 5AR
Tel: Wokingham 784774
Telex: 847178 848179
Hewlett-Packard Ltd
The Graftons
Stamford New Road
GB-Altrincham, Cheshire
Tel: (051) 928-9021
Telex: 668068

ITALY
Hewlett-Packard Italiana S.p.A.
Via Amerigo Vesputti 2
I-20124 Milan
Tel: (2) 6251 (10 lines)
Cable: HEWPAKIT Milan
Telex: 32046
Hewlett-Packard Italiana S.p.A.
Via Pietro Maroncelli 40
(ang. Via Vercelli)
I-35100 Padova
Tel: 66 40 62 66 31 88
Telex: 32046 via Milan
Medical Only
Hewlett-Packard Italiana S.p.A.
Via Medaglia d'Oro 2
I-56100 Pisa
Tel: (050) 2 32 04
Telex: 32046 via Milan
Hewlett-Packard S.p.A.
Via G. Arminelli 10
I-00143 Rome Eur
Tel: (6) 5912943 5
Telex: 61514
Cable: HEWPAKIT Rome
Hewlett-Packard Italiana S.p.A.
Via San Quintino 46
I-10121 Turin
Tel: 53 82 64 54 84 68
Telex: 32046 via Milan
Medical Calculators Only
Hewlett-Packard Italiana S.p.A.
Via Principe Nicola 43 G C
I-95126 Catania
Tel: (095) 370505

LUXEMBURG
Hewlett-Packard Benelux
S.A. N.V.
Avenue de Col-Vert 1
(Groenkraslaan)
B-1170 Brussels
Tel: (02) 672 22 40
Cable: PALOBEN Brussels
Telex: 23 494

NETHERLANDS
Hewlett-Packard Benelux N.V.
Weerdestein 117
P.O. Box 7825
NL-Amsterdam 1011
Tel: (020) 5411522
Cable: PALOBEN Amsterdam
Telex: 13 216 hepa nl

NORWAY
Hewlett-Packard Norge A/S
Nesveien 13
Box 149
N-1344 Haslum
Tel: (02) 53 83 60
Telex: 16621 hpnas n

POLAND
Analytical Medical Only
Hewlett-Packard
Warsaw Technical Office
Szpitalna 1
00-120 Warsaw
Tel: 268031
Telex: 812453

PORTUGAL
Electra-Empresa Técnica de
Equipamentos Electricos S.a.r.l.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-Lisbon 1
Tel: (1) 68 60 72
Cable: ELECTRA Lisbon
Telex: 12598
Mundinter
Intercomércio Mundial de Comércio
Sarl Avenida Antonio Augusto
de Aguiar 136
P.O. Box 2761
P-Lisbon
Tel: (1) 53 21 31 7
Cable: INTERCAMBIO Lisbon

SPAIN
Hewlett-Packard Española, S.A.
Jeréz No 3
E-Madrid 16
Tel: (1) 458 26 00 (10 lines)
Telex: 23515 hpe
Hewlett-Packard Española, S.A.
Milanesado 21-23
E-Barcelona 17
Tel: (3) 203 6200 (5 lines)
Telex: 52603 hpe e
Hewlett-Packard Española, S.A.
Av Ramon y Cajal, 1
Edificio Sevilla I, planta 9
E-Seville
Tel: 64 44 54 58

Hewlett-Packard Española S.A.
Edificio Albia II 7-8
E-Bilbao
Tel: 23 83 06 23 82 06
Calculators Only
Hewlett-Packard Española S.A.
Alvaro Bazan, 12
(Edificio Luz)
E-Valencia - 10
Tel: 60 42 00

SWEDEN
Hewlett-Packard Sverige AB
Enighetsvägen 1-3
Fack
S-161 20 Bromma 20
Tel: (08) 730 05 50
Cable: MEASUREMENTS
Stockholm
Telex: 10721
Hewlett-Packard Sverige AB
Hälsjöplan 9C
S-431 41 Molndal
Tel: (031) 27 68 00 01
Telex: Via Bromma

SWITZERLAND
Hilti-Packard (Schweiz) AG
Zürcherstrasse 20
P.O. Box 64
CH-8952 Schlieren Zurich
Tel: (01) 98 18 21
Cable: HPAG CH
Telex: 53933 hpag

Hewlett-Packard (Schweiz) AG
9, chemin Louis-Pictet
CH-1214 Vernier Geneva
Tel: (022) 41 49 50
Cable: HEWPAKSA Geneva
Telex: 27 333 hpsa ch

TURKEY
Telekom Engineering Bureau
Sığık Sok No 15-1
Ayaspaşa-Beyoğlu
P.O. Box 437, Beyoğlu
TR-Istanbul
Tel: 49 40 40
Cable: TELEATION Istanbul

UNITED KINGDOM
Hewlett-Packard Ltd
King Street Lane
Winnemah, Wokingham
GB-Berkshire RG11 5AR
Tel: Wokingham 784774
Telex: 847178 848179
Hewlett-Packard Ltd
The Graftons
Stamford New Road
GB-Altrincham, Cheshire
Tel: (051) 928-9021
Telex: 668068

Hewlett-Packard Ltd.
c/o Makro
South Service Wholesale Centre
Amber Way
Halesowen Industrial Estate
GB-Halesowen, Worcs
Tel: Birmingham 7860
Hewlett-Packard Ltd
4th Floor
Wedge House
799, London Road
GB-Thornton Heath CR4 6XL,
Surrey
Tel: (01) 684 0105
Telex: 946825
Hewlett-Packard Ltd
c/o Makro
South Service Wholesale Centre
Wear Industrial Estate
Washington
GB-New Town, County Durham
Tel: Washington 464001 ext: 57/58
Hewlett-Packard Ltd. s registered
address for V.A.T. purposes
only:
70, Finsbury Pavement
London, EC2A1SX
Registered No: 690597

USSR
Hewlett-Packard USSR
c/o Commercial Office
American Embassy (Box M)
A-1091 Vienna, Austria
Tel: 221-79-71
Telex: 7825 hewpak SU
YUGOSLAVIA
Iskra-Standard Hewlett-Packard
Topniska 58 3
61000 Ljubljana
Tel: 315-879 321-674
Telex: 31300

**SOCIALIST COUNTRIES
PLEASE CONTACT:**
Hewlett-Packard S.A.
7, rue du Bois-du-Lan
P.O. Box 349
CH-1217 Meyrin 1 Geneva
Switzerland
Tel: (022) 41 54 00
Cable: HEWPAKSA Geneva
Telex: 2 24 86

AFRICA, ASIA, AUSTRALIA

ANGOLA
Telectra
Empresa Técnica de
Equipamentos
Electricos, S.A.R.L.
R. Barbosa Rodrigues, 42-1 DT
Caixa Postal 6437-Luanda
Tel: 35515 6
Cable: TELECTRA Luanda

AUSTRALIA
Hewlett-Packard Australia
Pty Ltd
31-41 Joseph Street
Blackburn, Victoria 3130
Tel: 89-6351, 89-6306
Telex: 21561
Cable: HEWPAK Melbourne
Hewlett-Packard Australia
Pty Ltd
31 Bridge Street
Pymble
New South Wales, 2073
Tel: 449-6566
Telex: 21561
Cable: HEWPAK Sydney
Hewlett-Packard Australia
Pty Ltd
97 Churchill Road
Prospect 5082
South Australia
Tel: 44 8151
Cable: HEWPAK Adelaide
Hewlett-Packard Australia
Pty Ltd
141 Stirling Highway
Claremont W.A. 6010
Tel: 66-5455
Telex: 93859
Cable: HEWPAK
Hewlett-Packard Australia
Pty Ltd
121 Wollongong Street
Fyshwick A.C.T. 2609
Tel: 95 3733
Hewlett-Packard Australia
Pty Ltd
5th Floor
Teachers Union Building
495-499 Boundary Street
Spring Hill 4000 Queensland
Tel: 29-1541
Telex: AA-42133

CEYLON
United Electronics Ltd
P.O. Box 681
60, Park St
Colombo 2
Tel: 26696
Cable: HOTPOINT Colombo

CYPRUS
Kyronikos & Xenopoulos Rd
P.O. Box 1152
CY-Nicosia
Tel: 45029 29
Cable: KYRONIKOS PANDEMIS

HONG KONG
Schmidt & Co (Hong Kong) Ltd.
P.O. Box 297
Comlight Centre
39th Floor
Connaught Road, Central
Hong Kong
Tel: 240168, 232735
Telex: HK4766
Cable: SCHMIDTCO Hong Kong

INDIA
Blue Star Ltd
Kastur Buildings
Jamshedji Tata Rd
Bombay 400 020
Tel: 29 50 21
Telex: 3751
Cable: BLUEFROST

Blue Star Ltd
Sabas
414 2 Vir Savarkar Marg
Prabhadevi
Bombay 400 025
Tel: 45 78 87
Telex: 4093
Cable: FROSTBLUE
Blue Star Ltd
Band Box House
Prabhadevi
Bombay 400 025
Tel: 45 73 01
Telex: 3751
Cable: BLUESTAR
Blue Star Ltd
14 40 Civil Lines
Kampur 208 001
Tel: 6 88 82
Cable: BLUESTAR
Blue Star Ltd
7 Hare Street
P.O. Box 506
Calcutta 700 001
Tel: 23-0131
Telex: 655
Cable: BLUESTAR
Blue Star Ltd
Blue Star House
34 Ring Road
Lajpat Nagar
New Delhi 110 024
Tel: 62 32 76
Telex: 2463
Cable: BLUESTAR
Blue Star Ltd
Blue Star House
11 11A Magarath Road
Bangalore 560 025
Tel: 55668
Telex: 430
Cable: BLUESTAR
Blue Star Ltd
Meekashi Mandiran
xxx 1678 Mahatma Gandhi Rd
Cochin 682 016 Kerala

Blue Star Ltd
1-1-117-1
Sarojini Devi Road
Secunderabad 500 003
Tel: 7 63 91, 7 73 93
Cable: BLUEFROST
Telex: 459

Blue Star Ltd
23 24 Second Line Beach
Madras 600 001
Tel: 23954
Telex: 379
Cable: BLUESTAR
Blue Star Ltd
Nathraj Mansions
2nd Floor Bistapur
Jamshedpur 831 001
Tel: 38 04
Cable: BLUESTAR
Telex: 240

INDONESIA
BERCA Indonesia P.T.
P.O. Box 496
1st Floor J.L. Cikini Raya 61
Jakarta
Tel: 56038, 40369, 49886
Telex: 2895 Jakarta

IRAN
Multi Corp International Ltd.
Avenue Soraya 130
P.O. Box 1212
IR-Teheran
Tel: 83 10 35-39
Cable: MULTICORP Tehran
Telex: 2893 mci tn

ISRAEL
Electronics & Engineering
Div. of Motorola Israel Ltd
17 Amnaday Street
Tel-Aviv
Tel: 36941 (3 lines)
Cable: BASTEL Tel-Aviv
Telex: 33569

JAPAN
Yokogawa-Hewlett-Packard Ltd
Onyashi Building
1-59-1 Yoyogi
Shibuya-ku, Tokyo
Tel: 03-370-2581 92
Telex: 232-2924YHP
Cable: YHPMARKET TOK 23-724
Yokogawa-Hewlett-Packard Ltd
Nagai Ibaragi Bldg
2-2-8 Kasuga
Ibaragi-Shi
Osaka
Tel: (0726) 23-1641
Telex: 5342-385 YHP OSAKA
Yokogawa-Hewlett-Packard Ltd
Nakano Building
No. 24 Kamsasazuma-cho
Nakamura-ku, Nagoya City
Tel: (052) 571-5171

Yokogawa-Hewlett-Packard Ltd
Tangway Building
2-24-1 Tsutsumi-cho
Kanagawa-ku
Yokohama 221
Tel: 045-312-1252
Telex: 382-3204 YHP YOK

Yokogawa-Hewlett-Packard Ltd
Mito Mitsui Building
1-4-73 San-no-maru
Mito, 310
Tel: 0292-25-7470
Yokogawa-Hewlett-Packard Ltd
Inoue Building
1348-3, Asahi-cho, 1-chome
Atsugi, 243
Tel: 0462-24-0452

KENYA
Technical Engineering Services
P.O. Box 18311
Nairobi, Kenya
Tel: 57726
Cable: PROTTON

KOREA
American Trading Company
Korea
I.P.O. Box 1103
Dae Kyung Bldg., 8th Floor
107 Sejong-Ro
Chongro-Ku, Seoul
Tel: (4 lines) 73-8924-7
Cable: AMTRACO Seoul

KUWAIT
Al Khadrya Trading &
Contracting Co.
Al Saor Street
Michaan Bldg. No. 4
Kuwait
Tel: 42 99 10
Cable: VISCOUNT

LEBANON
Mustapha & Company Ltd
Dismam Chambers
Abdullah Haroon Road
Karachi 3
Tel: 511027, 512927
Cable: COOPERATOR Karachi

Malaysia
MECOMB Malaysia Ltd
2 Lorong 13 BA
Section 13
Petaling Jaya Selangor
Cable: MECOMB Kuala Lumpur

MOZAMBIQUE
A.N. Goncalves Ltd
162 1 Apt 14 Av. D. Luis
Caxa Postal 107
Lourenco Marques
Tel: 27091
Telex: 6-203 Nagon Mo
Cable: NEGON

NEW ZEALAND
Hewlett-Packard (N.Z.) Ltd
94-96 Dixon Street
P.O. Box 9447
Courtenay Place,
Wellington
Tel: 59-559
Telex: 3898
Cable: HEWPAK Wellington

Hewlett-Packard (N.Z.) Ltd
Pakuranga Professional Centre
267 Pakuranga Highway
Box 51092
Pakuranga
Tel: 569-651
Cable: HEWPAK, Auckland

Analytical Medical Only
Dental & Medical Supply Co. Ltd
Scientific Division
79 Carlton Gore Road
Newmarket
P.O. Box 1234
Auckland
Tel: 75-289
Cable: DENTAL Auckland

NIGERIA
The Electronics
Instrumentation Ltd
N6B 770 Oyo Road
Olusegun House
P.M.B. 5402
Ibadan
Tel: 22325
Cable: THETEIL Ibadan

The Electronics Instrumenta-
tions Ltd (TEIL)
16th Floor Cocoa House
P.M.B. 5402
Ibadan
Tel: 22325
Cable: THETEIL Ibadan

PAKISTAN
Mustapha & Company Ltd
Dismam Chambers
Abdullah Haroon Road
Karachi 3
Tel: 511027, 512927
Cable: COOPERATOR Karachi
Mustapha & Company Ltd
388, Sublime Town
Rawalpindi
Tel: 41924
Cable: FEMUS Rawalpindi

PHILIPPINES
Electromex, Inc.
8th Floor, Amagamatad
Development Corp. Bldg
Ayala Avenue, Makati, Rizal
C.C.P. Box 1028
Makati, Rizal
Tel: 86-16-87, 87-76-77
Cable: ELEMEX Manila

SINGAPORE
Mechanical & Combustion
Engineering Company Pte.,
Ltd.
10-12, Jalan Kilang
Red Hill Industrial Estate
Singapore 3
Tel: 647151 (7 lines)
Cable: MECOMB Singapore

Hewlett-Packard Singapore
(Pte.) Ltd
Bk. 2, 6th FLOOR, Jalan
Bukit Merah
Redhill Industrial Estate
Alexandra P.O. Box 87,
Singapore 3
Tel: 633022
Telex: HPSG RS 21486
Cable: HEWPAK, Singapore

SOUTH AFRICA
Hewlett-Packard South Africa
(Pty.) Ltd
Hewlett-Packard House
Daphne Street, Wendywood
Sandton, Transvaal 2001
Tel: 802-1040
Telex: SA43-4782JH
Cable: HEWPAK

Hewlett-Packard South Africa
(Pty.) Ltd
Breechside House
Bree Street
Cape Town
Tel: 2-0941 2 3
Cable: HEWPAK Cape Town
Telex: 0006 CT

Hewlett-Packard South Africa
(Pty.) Ltd
641 Ridge Road, Durban
P.O. Box 37099
Overport, Durban, 4067
Tel: 68-6102
Telex: 6-7854

TAIWAN
Hewlett-Packard Taiwan
39 Chung Smao West Road
Sec. 1 Overseas Insurance
Corp. Bldg. 7th Floor
Taipei
Tel: 389160, 1 2
Telex: TP824 HEWPAK
Cable: HEWPAK Taipei

Hewlett-Packard Taiwan
38, Po-Ai Lane, San Min Chu
Kaohsung
Tel: 297319

THAILAND
UNIMESA Co., Ltd.
Eskom Research Building
Bangkok Sukumvit Ave.
Bangkok
Tel: 932387, 930338
Cable: UNIMESA Bangkok

UGANDA
Uganda Tele-Electric Co., Ltd.
P.O. Box 4449
Kampala
Tel: 57279
Cable: COMCO Kampala

VIETNAM
Peninsular Trading Inc.
P.O. Box H-3
216 Hien-Vuong
Saigon
Tel: 20-805, 93398
Cable: PENTRA, SAIGON 242

ZAMBIA
R.J. Tilbury (Zambia) Ltd
P.O. Box 2792
Lusaka
Zambia, Central Africa
Tel: 73793
Cable: ARJAYTEE, Lusaka

**MEDITERRANEAN AND
MIDDLE EAST COUNTRIES
NOT SHOWN PLEASE CONTACT:**
Hewlett-Packard S.A.
Mediterranean and Middle
East Operations
35, Kolokotroni Street
Platia Kefallionu
GR-Kifissia-Athens
Telex: 21-6588
Cable: HEWPAKSA Athens

OTHER AREAS NOT LISTED, CONTACT:
Hewlett-Packard
Export Trade Company
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
TWX: 910-373-1267
Cable: HEWPAK Palo Alto
Telex: 034-8300, 034-8493

